


# Parts Diagram ■




Katera™ 4-Leg Chair

March 2020

optional upholstered  
seat & back



optional wood  
seat & back



# ■ Katera™ 4-Leg Chair

## Parts Diagram

.XX = Select Color

Items 12 & 13 must be configured,

Item	Part Number	Item Description	Item	Part Number	Item Description
1	KA.BR211	Glides, Standard (set of four 1A, 2B, 3C, 4D)	16	KA.DA132	Wood Back, Natural on Beech (wood chair only)
	KA.BR212	Glides, Felt (set of four 1A, 2B, 3C, 4D)		KA.DA131	Wood Back, Florence Walnut on Beech (wood chair only)
2	KA.BR001	Frame with Arms, Black		KA.DA135	Wood Back, River Cherry on Beech (wood chair only)
	KA.BR003	Frame with Arms, Cottonwood		KA.DA136	Wood Back, Monticelo Maple on Beech (wood chair only)
	KA.BR020	Frame with Arms, Chrome		KA.DA137	Wood Back, Cherry Storm on Beech (wood chair only)
	KA.85.1111.XX	Frame with Arms, Other Color		KA.DA138	Wood Back, Cinnamon on Beech (wood chair only)
3	KA.BR111	Plastic Back, Black (poly chair only)		KA.DA139	Wood Back, Cocoa on Beech (wood chair only)
	KA.BR113	Plastic Back, Warm Grey (poly chair only)		KA.DA140	Wood Back, Eclipse on Beech (wood chair only)
	KA.BR114	Plastic Back, Chocolate (poly chair only)	17	KA.BR121	Wood Seat, Florence Walnut on Beech (wood chair only)
	KA.BR115	Plastic Back, Cool Grey (poly chair only)		KA.BR122	Wood Seat, Natural on Beech (wood chair only)
	KA.BR116	Plastic Back, Sky Blue (poly chair only)		KA.BR125	Wood Seat, River Cherry on Beech (wood chair only)
	KA.BR117	Plastic Back, Poppy Red (poly chair only)		KA.DA126	Wood Seat, Monticelo Maple on Beech (wood chair only)
	KA.BR118	Plastic Back, Cottonwood (poly chair only)		KA.DA127	Wood Seat, Cherry Storm on Beech (wood chair only)
4	KA.BR101	Plastic Seat, Black (poly chair only)		KA.DA128	Wood Seat, Cinnamon on Beech (wood chair only)
	KA.BR103	Plastic Seat, Warm Grey (poly chair only)		KA.DA129	Wood Seat, Cocoa on Beech (wood chair only)
	KA.BR104	Plastic Seat, Chocolate (poly chair only)		KA.DA130	Wood Seat, Eclipse on Beech (wood chair only)
	KA.BR105	Plastic Seat, Cool Grey (poly chair only)	18	KA.BR203	Strip, Metal (wood chair only)
	KA.BR106	Plastic Seat, Sky Blue (poly chair only)	19	AK.HW046	Screw, ABC 3 x 10 C/P (wood chair only)
	KA.BR107	Plastic Seat, Poppy Red (poly chair only)	20	AK.HW062	Flat Thread for Wood Backrest, Bight (wood chair only)
	KA.BR108	Plastic Seat, Cottonwood (poly chair only)	21	12.AK.HW101	Torx Screw, M.6 x 20mm Stainless Button Head (effective 3/25/20)
5	KA.BR201	Underseat Plastic Stacking Piece, Black		12.AK.HW102	Torx Screw, M.6 x 25mm Stainless Button Head (wood stool only) (effective 3/25/20)
6	KA.BR151	Poly Arm Left, Black	22	KA.BR011	Frame Armless, Black
	KA.BR153	Poly Arm Left, Warm Grey		KA.BR013	Frame Armless, Cottonwood
	KA.BR154	Poly Arm Left, Chocolate		KA.BR021	Frame Armless, Chromed
	KA.BR155	Poly Arm Left, Cool Grey		KA.85.1100.XX	Frame Armless, Other Color
	KA.BR156	Poly Arm Left, Sky Blue	23	KA.GANGER.NA	Ganger Kit, No Arm (includes both gangers and hardware)
	KA.BR157	Poly Arm Left, Poppy Red	24	KA.GANGER.WA	Ganger Kit, With Arm (includes both gangers and hardware)
	KA.BR158	Poly Arm Left, Cottonwood			
7	KA.BR161	Poly Arm Right, Black			
	KA.BR163	Poly Arm Right, Warm Grey			
	KA.BR164	Poly Arm Right, Chocolate			
	KA.BR165	Poly Arm Right, Cool Grey			
	KA.BR166	Poly Arm Right, Sky Blue			
	KA.BR167	Poly Arm Right, Poppy Red			
	KA.BR168	Poly Arm Right, Cottonwood			
8	12.AK.HW101	Torx Screw, M.6 x 20mm Stainless Button Head (effective 3/25/20)			
9	AK.HW044	Allen Screw, M.6 x 20mm C/P ZN/CHROME (armchair only)			
	AK.HW038	Allen Screw, M.6 x 20mm C/P ZN/BLACK (armchair only)			
10	12.AK.HW103	Torx Screw, M.6 x 30mm Stainless Button Head (armchair only) (effective 3/25/20)			
11	12.AK.HW100	Star Washer, M.6 (effective 3/25/20)			
12	KTRP	Upholstered Back, Replacement (uph chair only)			
13	KTRP	Upholstered Seat, Replacement (uph chair only)			
14	KA.209	Push Clip, Plastic			
15	KA.210	Bumper, Plastic			