


Ruckus [™] Collection
Stack Stool with and without Bookrack

September 2021



.XX = Select Color or Fabric RKRSC includes 12.0055.CZ.X.

RKRF includes the frame and glides attached at the factory.

Item 14 glide cap removal tool (not shown) is used to remove old glide caps for replacement of felt caps. See KI-RR-000030 for instructions.

Note: If Item 14 is out of stock, a flat head screw driver can be used to remove felt cap.

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	46.4302.XX.X	Backrest, 15" & 18" Stools	1	7	RKRSC	Assembly, Replacement Seat Cushion	1
2	46.4303.XX.X	Seat, 15" & 18" Stools	1	8	12.0055.CZ.X	Screw, #10-16 x 1/2" PTH Type AM T/F ZC	6
	46.4303.U.XX.X	Seat, 15" & 18" Upholstered Stools	1	9	46.4307.XX.X	Bockrack, Stackable Frame	1
3	RKRF	Weldment, 30" Stacking Glide Stool (uses 87.0723.XX frame)	1	10	12.7420.X	Screw, #10-16 x 3/4" Hex Serrated Washer Head	8
	RKRF	Weldment, 24" Stacking Glide Stool (uses 87.0722.XX frame)	1	11	10.0129.X	Felt Cap, Replacement (used on Felt Glide 10.0702.GFT.X)	4
	RKRF	Weldment, 30" Stacking Caster Stool (uses 87.0727.XX frame)	1	12	46.5417.BL.X	Caster Bushing, 1" O.D. 13 Gauge Tube	4
	RKRF	Weldment, 24" Stacking Caster Stool (uses 87.0726.XX frame)	1	13	46.4116.BL.A.X	Caster, 50mm Carpet	4
4	12.2801.X	Screw, 1/4 x 3/4" PH PAN HD HI-LO	6		46.4113.BL.A.X	Caster, 50mm Hard Floor	4
5	46.4306.BL.X	Shroud, Slip Fit Stacking Bumper	1	14	10.0138.X	Removal Tool, Felt Glide Cap (not shown) (see note)	1
6	10.0700.GPL.X	Glide, Nylon Base Swiveling	4				
	10.0700.GSL.X	Glide, Steel Base Swiveling	4				
	10.0702.GFT.X	Glide, Felt Base Swiveling (uses item 11)	4				



Changing Glide Stool to Caster StoolOption 1: Replace the glide stool frame with a caster stool frame using the RKRF part number.