


TES20(1/2/3)A(E/F/G)

Touchless Soap Dispenser, Square, 1~3 Spout, Controller and Tank Reservoir

Product Number Kit#	Spout#	Controller# / Tank
TES201AE#CP	TLK08001G#CP *1	TLK01101UA
TES202AE#CP	TLK08001G#CP *2	TLK01102U
TES203AE#CP	TLK08001G#CP *3	TLK01103U
TES201AF#CP	TLK08002G#CP *1	TLK01101UA
TES202AF#CP	TLK08002G#CP *2	TLK01102U
TES203AF#CP	TLK08002G#CP *3	TLK01103U
TES201AG#CP	TLK08003G#CP *1	TLK01101UA
TES202AG#CP	TLK08003G#CP *2	TLK01102U
TES203AG#CP	TLK08003G#CP *3	TLK01103U


Spout



Item	Part	Description
1	THP3491#CP	Spout Nozzle Piece (Square)
2	THP3497	Screw (1 pc)
3	THP3496	Filter
4	THP3342	Blue Air Hose (L=66-15/16", 1700mm)
5	THP3341	Clear Soap Hose (L=78-3/4", 2000mm)
6	THP3439	Hose Clamp
7	THP3487	Screw (1 pc, for TLK08001G#CP spout only)
8	THP3489	Nut w/ Gaskets and Slip Washer
9	TLK08001G#CP	Spout Square
	TLK08002G#CP	Spout Square Semi-Vessel
	TLK08003G#CP	Spout Square Vessel

Touchless Soap Dispenser, Square, 1~3 Spout, Controller and Tank Reservoir

Controller and Tank Reservoir



Item	Part	Description
C1	THP3343	Tank Joint x1 for TES201A* Tank Joint x2 for TES202A* Tank Joint x3 for TES203A*
C2	THP3344	Soap and air pump x1 for TES201A* Soap and air pump x2 for TES201A* Soap and air pump x3 for TES201A*
C3	THP3391	Controller Board
C4	THP3346	Ground wire w/ screws
C5	THP3347	Float switch
C6	THP3348	Sensor sockets
C7	THP3349	Float switch connector
C8	THP3350	Soap tank bracket set
C9	THP3351	Soap tank cap
C10	THP3352	Soap tank
C11	THP3364	Cap
C12	TLK01101UA	Controller for 1 Spout & Reservoir
	TLK01102U	Controller for 2 Spout & Reservoir
	TLK01103U	Controller for 3 Spout & Reservoir
C13	THP3374	Mount Bracket