


Parts Diagram ■

Torsion Air® Nesting Armless Chair

July 2020



.XX = Select Color

PMR = Product Modification Request

TARC ordered with or without shroud. With shroud includes items 3 & 4. Without shroud is just TARC.

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	46.3333.XXMH.X	Assembly, Backrest	1	9	46.5417.BL.X	Bushing, 13 Gage Tube Caster	4
2	TARC	Seat Cushion, Upholstered (see note)	1	10	09.0440.BL.X	Caster, 60mm Diameter Hard, Black (soft floor)	4
3	46.3344.BL.X	Shroud, Nesting Chair Seat	1		09.0440.CH.X	Caster, 60mm Diameter Hard, Chrome (soft floor)	4
4	12.9011.X	Cap Screw, M5 x 30 CLS 10.9 FSHCS PLN	4		09.0441.BL.X	Caster, 60mm Diameter Soft, Black (hard floor)	4
5	PMR	Replacement Frame, Torsion Air	1	11	10.0150.X	Glide, Bell	4
6	PT.06.7012.BL.X	Cap, Back Support	2	12	PT.44.7005.ZN.X	Plate, Seat Support	1
7	PT.06.7007.X	Bushing, Seat Pivot	2	13	13.0332.X	Screw, 5/16-18 x 1" Hex HD T/C Type F w/ Patch	4
8	46.0385.BL.X	Cap, Tube End	2	14	PT.06.7006.BL.X	Cover, Seat Plate	1