


Washbasin - LISSÉ

LISSÉ Three-hole basin mixer with pop-up waste - Dark Chrome

Article number: 20 713 845-19





Washbasin - LISSÉ
LISSÉ Three-hole basin mixer with pop-up waste - Dark Chrome
Article number: 20 713 845-19

Spare parts list

Position	Quantity used	Item Number	Spare part	Delivery time (Working days)
1	1	09 31 09 120-19	pull-rod	60
2	1	90 11 84 013 00-19	spout	50
3	2	04 30 04 019 00 90	hose	2
4	1	09 31 11 012 90	pin	2
5	1	04 30 11 038 75 90	fixing set	2
6	1	09 20 84 025-19	handle (hot)	60
7	1	04 17 11 055 51 90	side panel	2
8	1	90 90 03 151 00 90	top	2
9	1	09 20 84 024-19	handle (cold)	60
10	2	09 27 84 023-19	rosette	60
11	2	09 14 10 098 90	seal	2
12	2	09 18 40 206 90	ring	2
13	2	04 23 10 032 78 90	fixing set	2
14	1	04 17 11 055 50 90	side panel	2
15	1	90 90 03 150 00 90	top	2
16	2	90 23 30 040 00-19	threaded connector	-
Spare part can no longer be ordered, please order the replacement item				
17	1	90 11 01 001 00-19	pop-up waste	50