
MOCKETT

PART #


WCS8

310.318.2491 • 800.523.1269 • www.mockett.com




- USB port is for charging use ONLY.
- Wireless output is 10W Max.
- Mobile device must be equipped with a wireless charging receiver (Wireless charging accessories not included.) Check mobile manufacturer for compatibility.
- Cord length is 4 ft.
- Power adapter dimension is 1-27/32" X 1-1/2" X 29/32".

2




Install the unit into the cut out and be sure it is fully level on the surface. Use of adhesive is recommended for a more secure fitting (Not included).




Position the mobile device on the center of the charging area. The charging icon will activate on the device's screen when properly aligned at the center of the charging area.

1




Determine the position and location of the unit on the work surface. Cut the hole at 2-3/8 " DIA.

3



Plug in the USB cord from the unit to the power adapter. Plug the power adapter into a nearby outlet (outlet should be close enough to where power cord is not taut or strained) and unit is ready for use.

5



For tethered USB charging access(non-wireless) rotate the cover until you see USB port.

TABLE OF CONTENTS:



.....1X WCS8



.....1X Power Adapter