

MOCKETT

PART # PCS36/2S/B


310.318.2491 • 800.523.1269 • www.mockett.com




- For use on a normally dry work surface.
- Table thickness is 3/4 "MIN. to 1-11/16" MAX.
- Dimensions for plugs are $1-11/32" \times 1-1/32" \times 7/8"$.
- USB-A ports are for charging use only.
- Please use applicable adapter from data tree. (See PCS data tree page 2 for more information.)




Place the metal clips near the front and back of each side of the unit. (NOTE: Metal clips are for use in hard surface material only as an optional mounting means.)




Optional wire manager.




Secure unit by turning bottom wing clamp.



Determine the position and location of the unit on the work surface. Cut the hole at 16-1/4" X 4". Place and allow enough clearance for unit operation. DO NOT place unit where the cables are strained or trapped.



Guide the power cords through the cut out. Install the unit into the cut out and make sure it is fully leveled onto the surface.





PART #

PCS Data Tree


310.318.2491 • 800.523.1269 • www.mockett.com

1.) Select the appropriate adapter from the chart below. (example: Panduit Mini-Com Series jack would use "FFF" adapter marked on back of adapter.)





- 2.) Snap Jack into adapter following the instructions provided with the jack.
- 3.) Once assembled, snap adapter into the notched, square holes in the orientation shown.



NOTE:

Please verify fit of jack in adapter before ordering large quantities as manufacturer designs may change without notice.