
ASA7 pneumatic mechanism operating instructions



Top view (as seated)

- 1 Seat height adjustment:
 - Lift tab up to adjust seat height
- 2 Back tension adjustment:

Turn knob clockwise to increase tension, turn counterclockwise to lessen tension

3 Back tilt adjustment:

Turn knob clockwise to unlock tilt, turn counterclockwise to lock tilt

