


Parts Diagram ■

Torsion Air® Stack Chair
4-Leg Armchair

September 2019



.XX = Select Color

TARF includes Items 7, 8, 13, 14, 15 & 17.

TARC ordered with or without shroud. With shroud includes items 10 & 11. Without shroud is just TARC.

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	46.3333.XXMH.X	Assembly, Backrest	1	10	46.3346.BL.X	Shroud, Stacking Chair Seat	1
2	12.9011.X	Cap Screw, M5 x 30 CLS 10.9 FSHCS PLN	4	11	12.0055.CZ.X	Screw, #10-16 x 1/2 PTH Type AB T/F BLK ZC	5
3	46.3338.R.BL.X	Cap, Arm, Right	1	12	12.0011.X	Screw, M6 x 18 PPH "BosScrew"	4
4	46.3338.L.BL.X	Cap, Arm, Left	1	13	53.0004.RH.RXXX	Glide, Plastic, Right Rear	1
5	12.0696.TR.X	Screw, 8 x 5/8 TX OV HD T-B BLK OX	2		PT.06.6046.RRSX	Glide, Stainless, Right Rear	1
6	TARF	Replacement Frame, Torsion Air (see note)	1	14	53.0004.LH.RXXX	Glide, Plastic, Left Rear	1
7	PT.06.6048.XXX	Bumper, Stacking	2		PT.06.6046.LRSX	Glide, Stainless, Left Rear	1
8	PT.06.7012.BL.X	Cap, Back Support	2	15	53.0005.XXX	Glide, Front Torsion	2
9	TARC	Seat Cushion, Upholstered (see note)	1		PT.06.6045.FS.X	Glide, Front Torsion	2
				17	PC.12.0583.X	Screw, #8 x 1/2" Phillips Flat Head Type B	2