


Parts Diagram ■

Torsion Air® Stack Chair
4-Leg Armless Chair

September 2019



.XX = Select Color

TARF includes Items 4, 5, 10, 11, 12 & 13.

TARC ordered with or without shroud. With shroud includes items 7 & 8. Without shroud is just TARC.

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	46.3333.XXMH.X	Assembly, Backrest	1	9	12.0011.X	Screw, M6 x 18 PPH "BosScrew"	4
2	12.9011.X	Cap Screw, M5 x 30 CLS 10.9 FSHCS PLN	4	10	53.0004.RH.RXXX	Glide, Plastic, Right Rear	1
3	TARF	Replacement Frame, Torsion Air (see note)	1		PT.06.6046.RRSX	Glide, Stainless, Right Rear	1
4	PT.06.6048.XXX	Bumper, Stacking	2	11	53.0004.LH.RXXX	Glide, Plastic, Left Rear	1
5	PT.06.7012.BL.X	Cap, Back Support	2		PT.06.6046.LRSX	Glide, Stainless, Left Rear	1
6	TARC	Seat Cushion, Upholstered (see note)	1	12	53.0005.XXX	Glide, Plastic, Front	2
7	46.3346.BL.X	Shroud, Stacking Chair Seat	1		PT.06.6045.FS.X	Glide, Stainless, Front	2
8	12.0055.CZ.X	Screw, #10-16 x 1/2 PTH Type AB T/F BLK ZC	5	13	PC.12.0583.X	Screw, #8 x 1/2" Phillips Flat Head Type B	2

