


Parts Diagram

Torsion Air® Stack Chair
4-Leg Standard Flip-Up Tablet Arm Chair

September 2019



.XX = Select Color

TARF includes Items 5 and choice of glide.

TARC ordered with or without shroud. With shroud includes items 7 & 8. Without shroud is just TARC.

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	46.3333.XXMH.X	Assembly, Backrest	1	9	12.0011.X	Screw, M6 x 18 PPH "BosScrew"	4
2	12.9011.X	Cap Screw, M5 x 30 CLS 10.9 FSHCS PLN	4	10	53.0004.RH.RXXX	Glide, Plastic, Right Rear	1
3	TARF	Replacement Frame, Torsion Air LH Tablet (shown, see note)	1		PT.06.6046.RRSX	Glide, Stainless, Right Rear	1
	TARF	Replacement Frame, Torsion Air RH Tablet (see note)	1	11	53.0004.LH.RXXX	Glide, Plastic, Left Rear	1
4	12.9039.X	Screw, #10 x 5/8" PHPH BL (used to attach item 13)	5		PT.06.6046.LRSX	Glide, Stainless, Left Rear	1
5	PT.06.7012.BL.X	Cap, Back Support	2	12	53.0005.XXX	Glide, Plastic, Front	2
6	TARC	Seat Cushion, Upholstered (see note)	1		PT.06.6045.FS.X	Glide, Stainless, Front	2
7	46.3346.BL.X	Shroud, Stacking Chair Seat	1	13	TARM	Tablet Arm, LH (shown)	1
8	12.0055.CZ.X	Screw, #10-16 x 1/2 PTH Type AB T/F BLK ZC	5		TARM	Tablet Arm, RH	1

