


Parts & Service

Verge™ Individual & Multi-Feed Soap Tank Dispensers




Individual Soap Tank
(Shown with Crestt Soap Dispenser)

Verge™ Soap Dispenser - Crestt Series (6-3100)

Verge™ Soap Dispenser - Metro Series (6-3300)

Verge™ Soap Dispenser - Linea Series (6-3500)

Verge™ Soap Dispenser - Zen Series (6-3700)



Multi-Feed Soap Tank
(Shown with Crestt Soap Dispenser)

Table of Contents

Soap Tank Dispenser Components2

For questions regarding the operation, installation or maintenance of this product, visit bradleycorp.com or call 800.BRADLEY (800.272.3539).

Product warranties and parts information may also be found under “Resources” on our website at bradleycorp.com.



Soap Tank Dispenser Components

Parts List

Ref.	Part No.	Description
1	P15-535	Control Box, Individual
2	P15-541	Control Box, Multi-Feed Soap Tank
3	P15-534	Soap Tank, Individual
4	P15-540	Soap Tank, Multi-Feed
5	P15-531	Soap Pump, Individual
5	P15-565	Soap Pump, Multi-Feed
6	P15-532	Soap Pump Foam, Individual
6	P15-566	Soap Pump Foam, Multi-Feed
7	P15-536	Dispensing Nozzle, Foam Only (5 pk)
8	P15-533	Fill Tube, Individual
9	P15-538	Slip Joint Washer, Individual (5 pk)
10	P15-539	Nut, Individual Soap Tank
11	P15-602	Set Screw, Spring
12	P15-529	Cap Screw, M4 x 10 mm (5 pk)
13	P15-530	Allen Wrench, 3 mm (5 pk)

Ref.	Part No.	Description
14	P15-527	Locking Tab
15	P15-528	Wing Nut
16	A14-030	Battery Pack
17	A14-029	AC Adapter, Individual
18	P15-523	Silicone Washer, Crestt (5 pk)
19	P15-524	Silicone Washer, Metro (5 pk)
20	P15-525	Silicone Washer, Linea (5 pk)
21	P15-526	Silicone Washer, Zen (5 pk)
ns	P15-576	Soap Sprout Spacers, Crestt
ns	P15-596	Shank Assembly Kit, Crestt 6-3100
ns	P15-597	Shank Assembly Kit, Metro 6-3300
ns	P15-598	Shank Assembly Kit, Linea 6-3500
ns	P15-599	Shank Assembly Kit, Zen 6-3700

ns = not shown

