



CertainTeed *Technical Services Memo*

Subject:	Maintenance Instructions for Ecophon Akusto Wall Panel C acoustic wall panels		
Date:	January 10, 2024	Tel:	800-233-8990

Handling

Clean cotton gloves should be worn at all times, both during the initial ceiling assembly and any subsequent activity that may require a panel to be removed. When panels are removed they should be taken completely out of the grid and stored on a flat surface. Panels should be laid face to face in order to prevent unnecessary soiling and damage during their temporary displacement.

Cleaning

Akusto Wall Panel C acoustic panels with the Texona surface can withstand weekly dusting. It is to be carried out with a dry, soft (microfiber) cloth, soft brush or similar vehicle for this type of action. Weekly vacuum cleaning may also be carried out using the reduced suction inherent to the soft brush attachment typically used on textiles and curtains.

**If any portion of this information provokes a question, please contact
CertainTeed Technical Services.**