KEILHAUER

Hardware Included

Button head cap screw (x4)

1/4-20 x 1 1/4"


Tool Required

5/32" Hex Allen Key




Neesh


Seat Removal Instructions



Place the chair on its back on a blanket. Using the 5/32" hex key, remove the $1/4-20 \times 11/4$ " button head cap screw (x4).



Reverse steps 1 and 2 to reinstall the seat. Place the chair into its final position.



Remove the seat.