
Reeve

KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3 tel 416 759 5665 fax 416 759 5723 1800 724 5665 www.keilhauer.com

Seat Height Adjustment & Tilt Lock



Use the paddle shaped lever on the right side underneath the seat To raise lift your weight off the seat while lifting the front of the lever To lower sit on the seat while lifting the front of the lever

Use the paddled shaped lever on the left side underneath the seat

To unlock tilt pull the front of the lever up and tilt back slightly

To lock tilt recline to your desired position and push the front of the
lever down

Knee-tilt



Use the big round knob under the front of the seat
To increase tension turn the knob clockwise
To decrease tension turn the knob counter-clockwise