

1330 Bellevue Street • P.O. Box 8100 • Green Bay, WI 54308-8100
1-800-424-2432 • www.ki.com

Operating and Care Instructions

Pilot™ Task Chair

Save for future reference



Deriving Maximum Benefit From Your Pilot Task Chair

Back Angle Adjustment

Raise the lever to change the back angle; drop the lever to lock the back angle.

Seat Height Adjustment

To lower the seat - remain seated in chair and raise the lever.

To raise the seat - lift body weight slightly off the chair and raise the lever.

Seat Depth Adjustment

Push the lever in and move the seat forward or back ; release the lever to lock the seat depth.

Tilt Lock Adjustment

Raise the lever to allow seat and back to rock; drop the lever to prevent movement.


Tilt Tension Adjustment

Turn the knob clockwise to increase tension and counterclockwise to decrease tension.

Back Height Adjustment

To raise the back - grasp the lower edge of the back and raise the back to the desired height.

To lower the back - first raise the back to its uppermost limit and then allow the back to fall to its lowest limit.



Care of your Pilot Task Chair

Care of your Pilot task chair is easy.

It requires no more care than any other fine seating. Exclusive functional mechanisms and component integrity are thoroughly tested. A ten-year warranty covers structural integrity, while a one-year warranty covers upholstery.

Periodic light cleaning is all that is necessary. Be certain to vacuum upholstery frequently and thoroughly.

Use mild soap or detergent with luke-warm water and a soft, non-scratching cloth to clean plastic surfaces, upholstery, and powder-coated metal.

Stains and spots may require a more thorough cleaning. For this we recommend:

Fabric Upholstery - Use a foam-type cleaner such as Johnson Wax "Glory" or Earl Grissmer Co. "Blue Lustre" for general cleaning.

For more stubborn spots and stains, use Texie Chemical Co.'s "K2r". Always follow the manufacturer's directions.

Plastic parts and powder-coated finishes - Chewing gum and similar stubborn spots may be removed with cigarette lighter fluid. Wipe dry immediately. Sunnyside Plastic Cleaner is ideal for light cleaning. Buffing with

this product restores luster to smooth surfaces. Its anti-static properties help repel dust and dirt. High quality wax, such as Johnson's "Glo-Coat" or "Simonize", restores luster and protects the finish. Follow container directions and apply with a soft cloth and buff thoroughly.

Caution: Do not use dry cleaning agents on upholstery, or a coarse cloth when applying cleaning agents to smooth surfaces.