


# Parts Diagram ■

Apply™ Armless Task Chair

February 2024



.LXX = Select Laminate  
 ARSC includes 12.1160.X  
 15.1084.D uses 46.2995.XX.X  
 15.1078.X uses SIFT.015.X

| Item | Part Number     | Item Description   | Req Qty |
|------|-----------------|--|---------|
| 1    | APRLS           | Assembly, Molded Plywood Seat  | 1       |
|      | APRLS           | Assembly, Molded Plywood Seat w/ Upholstery                            | 1       |
| 2    | 87.0458.BL.X    | Assembly, Apply Pedestal Spider & Mechanism                            | 4       |
| 3    | PT.06.6040.BL.X | Handle, Pedestal   | 1       |
| 4    | 12.0565.X       | Screw, 1/4-20 x 1/2" Hex Head with Nylok                               | 1       |
| 5    | 15.1084.D       | Cylinder, Pneumatic Height Adjustment, Type D (used with plastic base) | 1       |
|      | 15.1078.X       | Cylinder, Gas Seat Height Adjustment (used with aluminum base)         | 1       |
| 6    | 46.2995.XX.X    | Base, 5 Blade Pedestal Stool   | 1       |
|      | SIFT.015.X      | Aluminum Base, Apply Task Chair  | 1       |
| 7    | 09.0440.BL.X    | Caster, 60mm Diameter Carpet (black only)                              | 5       |
|      | 09.0441.BL.X    | Caster, 60mm Diameter Hard Floor (black only)                          | 5       |
| 8    | ARSC            | Assembly, Replacement Seat Cushion                                     | 1       |
| 9    | 12.1160.X       | Screw, #12-16 x 1/2" #10 Truss Head                                    | 4       |