


Parts Diagram

Strive® Nesting Chair

Polyurethane and Upholstered Seat with Arms

November 2024



.XX = Select Color

PMR = Product Modification Request

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	PMR	Pressure Fit Back with Arm Frame	1	12	46.5382.R.XX.X	Cover, Arm Frame, RH	1
2	46.5368.XX	Arm Cap, Nesting Chair	2	13	46.5382.L.XX.X	Cover, Arm Frame, LH	1
3	12.0696.X	Screw, #8 x 5/8" TX OV HD T-B BLK OX	4	14	12.0266	Spring Pin, 1/4 x 1-1/2"	1
4	46.5367.XX.X	Board, Seat	1	15	12.0032.X	Clips, Tinnerman	4
5	42.0100	Mounting Plate, Seat Shroud	2	16	46.5369.XX.X	Cap, Tube End	2
6	46.5068.X	Clip, Cylindrica	6	17	46.0385.XX.X	Cap, Tube End	2
7	46.5365.XX.X	Shroud, Seat	1	18	46.5417.BL.X	Bushing, 1" OD Tube Caster	4
8	SNP.SEAT.XX.KD	Seat, Polyurethane	1	19	09.0440.BL.X	Caster, 60mm Diameter Carpet	4
9	SNRC	Seat, Upholstered	1		09.0441.BL.X	Caster, 60mm Diameter Hard Floor	4
10	46.5366.XX	Cover, Seat Mounting	1	20	10.0150.X	Glide, Bell	4
11	12.0228	Screw, 1/4-20 x 2-1/4" PPH MS ZC	4				