


# Parts Diagram

LimeLite™ Seating  
Armless Task Stool (Models LL61 & LL62)

March 2024



.XX = Select Color  
Item 3 includes Item 5.

| Item | Part Number    | Item Description                                  | Req Qty |
|------|----------------|---------------------------------------------------|---------|
| 1    | 46.6401.XX.X   | Shell, Poly Seat and Back One Piece               | 1       |
| 2    | 46.6401.XX.U.X | Shell, Uph. Seat and Poly Back One Piece          | 1       |
| 3    | LLRF           | Assembly, LimeLite Seat Support (see note)        | 1       |
| 4    | 12.0011.X      | Screw, M6 x 18mm Phillips Pan Head BosScrew       | 7       |
| 5    | 46.6416.XX.X   | Handle, Task Chair Height Adjust                  | 1       |
| 6    | 15.0120        | Foot Ring, Stool 20" Twist-to-Lock                | 1       |
| 7    | 15.1106.BL     | Stool Cylinder, Black Pneumatic Height Adjustment | 1       |
|      | 15.1107.XX     | Stool Cylinder, Pneumatic Height Adjustment       | 1       |
| 8    | 46.6411.XX.X   | Base, 27" 5-Blade Black Plastic                   | 1       |
|      | 46.6410.XX.X   | Base, 27" 5-Blade Aluminum                        | 1       |
| 9    | 09.0441.XX.X   | Caster, Dual Surface                              | 5       |
| 10   | LLRSC          | Seat, Upholstered                                 | 1       |
| 11   | 12.0511.X      | Screw, #10-16 x 5/8" Phillips Truss Head          | 5       |

