


Disassembly Instructions

Pillar Table

Material Type: A .Steel B. Wood C. Plastic



Procedure:

1. Remove the screws holding the legs to the table top and remove the top.
2. Remove the plastic casters from each leg.
3. Remove the screws from the stiffeners from the under side of the table.

All fasteners not explicitly tagged or shown are Material Type A: Steel

General Notes:

1. Disassembly time: 20-30 minutes
2. This procedure assumes basic familiarity with hand tools and furniture terminology: no specialized training is required
3. All materials removed and disassembled shall be sorted and segregated with like materials and disposed of or recycled according to recycling availability or waste acceptance

4. For items to be recycled, refer to KI's End of Life Recycling Matrix and KI's End of Life Recovery Options Matrix, available at www.ki.com


Required Tools



Gloves



Safety Glasses



#2 Phillips Screwdriver