


Airus stool height control operating instructions



Top view (as seated)

- ① **Seat height adjustment:**
Lift tab up to adjust seat height