



Flexxy mechanism operating instructions



Top view (as seated)



Left side view

- ① **Seat height adjustment:**
Lift tab up to adjust seat height
- ② **Back tension adjustment:**
Pull out then knob then turn clockwise to increase tension, turn counterclockwise to horizontal position to lessen tension
- ③ **Back tilt adjustment:**
Turn paddle clockwise to the vertical position to lock tilt, turn counterclockwise to horizontal position to unlock tilt
- ④ **Seat slider adjustment:**
Squeeze the tap below the middle of the seat to allow adjustment, release tab to lock position