


## Top View



- 1 **Back Tilt Adjustment:** Has 4 locking positions, turn knob towards the front of chair to lock, turn towards the rear to unlock
- 2 **Seat Slider Adjustment:** Lift tab to allow adjustment of seat forward and back, release tab to lock position
- 3 **Back Tension Adjustment:** 4 Settings, turn knob towards the rear of chair to loosen tension, turn forward to tighten tension
- 4 **Seat Height Adjustment:** Lift tab to adjust seat height, release tab to lock in place

## Available on

- Emmitt