



CARE AND CLEANING INSTRUCTIONS

- Check to see that all rubber feet are in place before using wire accessories.
- Clean with mild soap and rinse thoroughly after each use.
- Do NOT use scouring pads, abrasive cleaners, and harsh detergents.
- Dishwasher safe. Remove grid feet and bumpers before placing in dishwasher.
- Some accessories are designed with a tight fit to help secure them into place.

LIMITED 1 YEAR WARRANTY

- Wire accessories are warranted to be free from defects in materials and workmanship for a period of 1 year from the date of purchase.
- Our warranty does not cover product failure or damage caused by abusive treatment, misuse, environmental factors or improper care and cleaning.
- No additional warranties, express or implied are given.
- This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.
- Proof of purchase including date of purchase is required.

1333 Butterfield Road, Suite 200
Downers Grove, Illinois 60515, U.S.A.
Customer Care: 1 (800) 476-4106
elkay.com

Printed in China Rev (03/25) 74180102