

**DO NOT REMOVE
THIS TAG.**
PRODUCT INSTALLERS:



HON®

Convergence® Seating

Quick Guide

Congratulations on your new chair!

Quick Guide | Convergence®



Shown with seat control 4a.

1

Height and Width Adjustable Arms

Press the button while moving the arms up or down to raise or lower arm height. Adjust desired width of the arms using the lever under the seat. Armless option is also available.

2

Adjustable Lumbar

Easily slides up and down to increase lower back comfort.

3a

Pneumatic Seat Height Adjustment

To raise the seat, take your weight off the chair and lift the lever up. To lower the seat, place your full weight on the chair while lifting the lever.

3b

Tilt Lock

Push in the lever to lock the chair in an upright position. Pull the lever out to release and recline.

4

Seat Controls

4a

Simple Synchro-Tilt with Seat Slider

To adjust the ease of recline, turn the front knob clockwise to tighten the tilt tension and counter-clockwise to loosen. Includes seat depth adjustment. Lift underside lever to adjust seat depth.



4b

Swivel Tilt

To adjust the ease of recline, turn the front knob clockwise to tighten the tilt tension and counter-clockwise to loosen.



Scan to learn more!



Or visit hon.com/convergence

