

Make your space work®

HON®

To view the registered and unregistered trademarks owned and used by The HON Company, visit [hon.com/](http://hon.com/) protected-marks. Models, upholstery and finishes are subject to change without notice.

© 2022 The HON Company. Form No. H6008 (11/22)

The HON Company  
200 Oak Street, Muscatine, IA 52761  
800.833.3964 | [Check out hon.com](http://Check out hon.com)

# DO NOT REMOVE THIS TAG. PRODUCT INSTALLERS:

HON®



## Flexion™ Seating

Quick Guide

Congratulations on your new chair!

## Quick Guide | Flexion™



1

### Adjustable Arms

Pull the lever up to raise or lower arm-height. Fixed arms or armless options are also available.

2

### Flex Control

4-point seat suspension responds and adapts to user's movements without the need for manual adjustments.

3a

### Tilt Lock

Push the lever in to lock the chair in an upright position. Pull the lever out to release and recline.

3b

### Pneumatic Seat-Height Adjustment

To raise the seat, take your weight off the chair and lift the lever up. To lower the seat, place your full weight on the chair while lifting the lever.



Scan to learn more!



Or visit [hon.com/flexion](https://hon.com/flexion)

