

Grommet locations

On the user side, grommets can be specified in any combination of left, center, and right positions. All locations feed down to a metal wire management tray. If no grommet is specified, cords will route over the edge of the worksurface to the metal wire tray as needed.



Wire management and power

A PS-77 power module and a metal wire management tray come standard on the underside of the worksurface. Surface mounted devices plug into the PS-77, which features a 10' cord that routes through the interior of the height adjustable column base.



Note: The height adjustable column's power cord plugs into the power strip located in the base cabinet. For details, see the Cabinet power strip section below.

Cord routing

The height adjustable column features an open back, with space between the column base and shroud to accommodate wire management. Cords route down the column into the base cabinet, which includes hinged doors on the user side for interior access. The base cabinet features an open back, for direct wall access.



Cabinet power strip

A standard black power module with three outlets is mounted in the back left corner of the base cabinet. One outlet is occupied by the plug for the height-adjustable base.

The remaining two outlets are available for the PS-77 power module, and any additional power cords.

The three outlet power module includes a 9' cord, which exits through the back of the base cabinet to plug into your wall outlet.

