

# Asia: Installation method 1

Recommended installation using Standard Drain: VA code STD-UNI-PC, BN, PN, PB, ORB

The fitting of the base and or installation of the tub will be seen as acceptance of quality.

We strongly recommend that you use a suitably qualified installer. Instructions must be adhered to. We cannot accept responsibility of incorrect installation.

Victoria & Albert customer service representatives are not qualified to give advice on DIY installations.

If the tub has been painted ensure the contact area on the tub where the feet will fit has not been painted over as this could result in poor adhesion and possible failure.

**Important:** There are two ways of installing The Asia. For the correct instructions be sure the follow the relevant method:

**Black Resin Cradle (BRC) - Use method 1**

**Beech (BEE), Wenge Cradle (WEN) & Walnut (WAL) - Use method 2**

**Please note:** The silicone tube contains the correct amount of adhesive for the feet supplied. Be careful not to over apply on the first foot.

Silicone should be used before the expiration date printed on the tube. Additional supplies of general purpose clear medium/high modulus silicone are available from all good DIY stores. Do not use adhesives.

- a. Unpack black resin inserts and position parallel, approximately 33 1/2" apart. Adjust the metal feet inside the inserts so that they rest on the deck, and support the weight of the tub.



- b. Place the tub on the insert blocks and adjust positioning as necessary.
- c. Remove tub and mark position of the blocks on the deck through the hole in the center of the insert.



- d. Drill a pilot hole in the deck and fix the inserts using a suitable method. We recommend the hex head coach bolts provided in case the tub has to be moved at any time.

**Note:** Once fixed together the blocks and tub cannot be separated.

- e. Apply the silicone provided to the top of the insert and lower the tub into position.



- f. Fit the appropriate Victoria & Albert drain kit and connect the plumbing.

**Questions?**

**1.800.421.7189**