



INITIAL CONSTRUCTION CLEAN

After installation, wait 48 hours before proceeding with the construction/intensive clean.

- Sweep or dry vacuum the floor to remove dust, grit and debris.
- Apply a solution of alkaline cleanser, diluted as per the manufacturer's instructions, to the floor and leave for at least 5 minutes (or longer if manufacturer recommends) to react, before proceeding. Using a 150 to 175 rpm rotary machine fitted with suitable brushes, machine scrub the floor and then pick up the slurry with a mop or wet vacuum.
- The floor should then be rinsed with clean water and allowed to dry.



APPLICATION OF A FLOOR DRESSING

- Prior to the application of a floor dressing, ensure that the floor is completely stripped, clean and free from any contaminants. This will ensure that there is a good key between the dressing and the surface of the floor.
- Apply two or three thin coats of emulsion polish in accordance with the manufacturer's instructions, with either a proprietary polish applicator or Kentucky mop wrung out to prevent over-application of polish. The polish should be applied up to 150mm from the edges of the room and subsequent coats should be applied at 90° to the previous one. The final coat should be applied right up to the edges of the room.



ROUTINE MAINTENANCE

- The frequency of each of the operations is dependent upon the type and intensity of the traffic.
- Firstly, sweep or dry vacuum daily to remove dust and loose dirt.
- Secondly, spot mop frequently. Rinse the area with clean warm water and allow to dry.
- Thirdly, as required, and normally at least once per week, use a floor maintainer, diluted as per the manufacturer's instructions. Mop the floor and leave to dry. If a shine is required, the floor should be buffed with a 300 to 500 rpm rotary machine fitted with suitable fibre or nylon brushes.
- Regular buffing of SaarFloor-Systems Rubber Sheet and Tile will enhance its appearance.



REMOVAL OF FLOOR DRESSING

- An unsightly build-up of polish should be avoided. The polish should be removed regularly, the interval between application and removal depends on the wear conditions and the number of polish layers. (Normally six months in heavy traffic areas.)
- Apply a solution of emulsion polish stripper, diluted to the manufacturer's instructions, to the floor and leave for approximately 15 minutes. Machine scrub with a 150 to 175 rpm machine fitted with a suitable brush and then remove slurry with a wet vacuum. Thoroughly rinse the floor with clean warm water, pick up with a wet vacuum and allow to dry completely. The cycle of polish application and routine maintenance should then be repeated.



- For further guidance, contact Polyflor Customer Technical Support. Always follow the Health and Safety guidance provided.

REGULAR CLEANING IS MORE BENEFICIAL TO THE FLOORCOVERING AND MORE COST-EFFECTIVE THAN OCCASIONAL HEAVY CLEANING.



**SaarFloor
Systems**

RUBBER SHEET AND TILE

FLOORCARE

APPROVED MAINTENANCE PRODUCTS

The companies listed have products that are approved for use with Polyflor products. For full instructions for use, and health and safety guidelines, please contact the manufacturer.

PRODUCT	DR. SCHUTZ Tel: 01296 437827 www.dr-schutz.com	BRITISH NOVA Tel: 01295 251721	PROCHEM Tel: 0208 974 1515 www.prochem.co.uk	EVANS VANODINE Tel: 01772 322200 www.evansvanodine.co.uk	ECOLAB LTD Tel: 01793 511221 www.ecolab.com	DIVERSEY UK LTD Tel: 01604 405311 www.diversey.com	SELDEN RESEARCH Tel: 01298 26226 www.selden.co.uk
NEUTRAL CLEANSER	Active Cleaner	Liquid 99	Prodet	High Class	Brial Action Plus	Taski Jontec 300 Carefree Stride 1000	Neutral Scrubber Drier Detergent Sabre
ALKALINE CLEANSER	Clean and Strip	Novaways Novaways Multi Purpose Sanitiser	Alkleen Ultracac Renovate Powerclean	E.M.C Plus Versatile Lift HSC	Gloss Express Regain Regain Ultra Powerclean Imi Action Plus	Brillo Cleaner/ Degreaser Carefree Stride 2000 Sprint Hard Surface Cleaner Taski Jontec Forward	Multi-Purpose Cleaner Selcien S Triple
GERMICIDAL CLEANSER		Novacross Non food areas Novacross (unperfumed) Food areas	Protect	Final Touch Safe Zone Protect		Lifeguard Cleaner/ /Disinfectant Conc. Shield Lifeguard cleaner Disinfectant Trigger	Selgiene Selgiene Ultra Selective
MAINTAINER/ WASH & WAX	Floor Cleaner R1000	Novacare Novacare Lime-lite	Protreat	Clean & Shine	Indur XL Fresh Indur Brilliant Plus Satine Brilliant Plus Indur Restorer Spray	Carefree Maintainer Carefree Mop & Shine Carefree Stride 3000 Taski Tensol	Selsheen Fast Lane Low Foam Floor Maintainer
DRY BRIGHT EMULSION POLISH	Floor Shine	Nova Long Life Nova Long Life Satin Finish	Proshine	Sustain Mexepol Enhance	Isi Star Phazer Isi Star Gemstor Laser Satin Star Tuklar Medical	Carefree Satin Carefree Eturnum Carefree Emulsion	Seldur Selexel Diamond Brite
SEMI BUFFABLE EMULSION POLISH	Floor Mat	Nova Supercote				Carefree Buffable Floor Polish	Selglo
FULLY BUFFABLE EMULSION POLISH	Secura Hard Sealer	Nova Superphalte	Proshine		Tuklar Medical		
POLISH STRIPPER	Clean & Strip	Nova Starbrite Nova 2001	Prostrip	Easystrip Sure Strip	Benduroil Maxx Benduroil Forte Benduroil Top Strip	Carefree Stripper Carefree Speed Stripper	Selstrip Selspeed Selate
POWER CLEANER (Spot Cleaner)	Turbo Strip	Cleanol Lift	Superclean	Lift		Sprint Spitfire	Maxima

The data presented is correct at the time of printing. However, Polyflor Ltd. reserves the right to update this information as and when necessary.

For the latest information, please check our web site at www.polyflor.com

Polyflor Ltd, in providing this information, does not imply any equivalence between each of the different manufacturers' products, or that other products would prove unsatisfactory.

POLYFLOR LTD. PO BOX 3 RADCLIFFE NEW ROAD WHITEFIELD MANCHESTER M45 7NR UK
UK SALES DIRECT: +44 (0)161 767 1122 UK SAMPLE REQUESTS: +44 (0)161 767 2551
 EXPORT SALES DIRECT: +44 (0)161 767 1913 TECHNICAL SUPPORT: +44 (0)161 767 1912
 RECEPTION: +44 (0)161 767 1111 UK FAX: +44 (0)161 767 1128
 EXPORT FAX: +44 (0)161 767 1166 E-MAIL: INFO@POLYFLOR.COM
 WEBSITE: WWW.POLYFLOR.COM

James Halstead
FLOORING



POLYFLOR
COVERING THE WORLD