

PALLAS

MAINTENANCE & CLEANING

TABLE OF CONTENTS

- 1 Upholstery
- 2 Yarns
- 3 Polyurethane
- 4 Vinyl vs. Polyurethane
- 5 Cubicles
- 6 Finish-Specific Cleaning
- 7 Cleaning Codes (By Pattern)
- 8 Cleaning Codes (By Code)

UPHOLSTERY

W Clean only with water-based shampoo or foam upholstery cleaner. Do not over wet. Do not use dry cleaning solvents to spot clean. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and laundered.

- S Clean only with dry cleaning solvent. Do not saturate. Do not use water. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and dry cleaned.
- WS Clean with mild detergent or shampoo, foam or dry cleaning solvent as desired.

 Do not saturate with liquid. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and dry cleaned or laundered.
- X Do not clean with either water or solvent-based cleaner. Use vacuuming or light brushing only.

Water based cleaning agents* are often classified as upholstery shampoo. They are usually commercially available as foams, concentrates and dry components.

Cleaning can be either wet or dry, though some suggest a third category, damp.

Wet cleaning equipment using water is classified into two broad types: Rotary or hand-applied shampoo Water extraction (sometimes inaccurately referred to as a steam cleaning)

Two of the damp processes with water are: Dry foam Rotary mop (bonnet)

Dry systems use a granule or powder that incorporates a cleaning solvent or a non-water chemical solvent, which allows soil to be removed by subsequent vacuuming.

Pre-test your cleaning method on an inconspicuous area of the fabric to determine if color bleeds, shrinks the fabric texture or alters the character. If there is any doubt, seek the assistance of a professional cleaning service.

* Examples include Glamorene, Glory, Blue Lustre and Woolite.

1

YARNS

BELLA DURA

Bella-Dura fabrics are inherently stain resistant, so a mild soap and water solution is all that is needed to remove most stains. Any cleaning product that can be used on indoor/outdoor fabrics is safe to use on Bella-Dura* as well as bleach for tough stains. Always rinse with clean water and allow to air dry. Take care when mixing cleaners with bleach and work in a well ventilated area. Bella-Dura* fabrics are woven with fibers that dry easily; Bella-Dura* fabrics should always be air-dried and never tumble-dried.

©Bella-Dura is a registered trademark of Wearbest Sil-Tex Mills, Ltd.

PILE/CHENILLE

Regular care (weekly)

- Vacuum regularly using low suction
- Rotate reversible cushions regularly
- Protect from direct sunlight

Pilling can occur occasionally as a result of normal daily wear and should not be considered as a fault. Fibre pills can be removed by a battery operated pilling tool available from most haberdashery stores.

Q2 POLYESTER

Lyric uses Q2 yarns, which are OEKO-TEX® 100 certified and rigorously tested down to each individual color as each perform differently.

Q2 high-performance yarns give textiles the following attributes:

- Superior durability
- High abrasion resistance
- High light fastness values
- Free from chemical additives (conforms to Prop 65, AB 2998 and is free from FR chemicals)
- Skin safe and hypo-allergenic
- Easy to clean and bleach cleanable (most stains can be removed with simple soap and water; solvent-based stains such as permanent marker can be removed with acetone)
- Easy to disinfect (use household disinfectant products)

POLYURETHANE

Regular Cleaning and Maintenance (Dirt, Dust, Grime): Clean the soiled area with mild soap and water, then immediately rinse the surface with fresh water and wipe dry with a clean cloth.

Food Stains/Oils (Ketchup, Chocolate, Coffee, Tea, Juice): Wipe affected area with a soft cloth or sponge, then follow the regular cleaning and maintenance above.

Healthcare Disinfecting: Clean the area with the CDC-approved 10:1 water and household bleach mixture. Then, immediately rinse the disinfected area with fresh water and wipe dry with a clean cloth.

Healthcare Stains (Blood, Urine, Betadine, Disinfectant): Clean the soiled area with a 20% (5:1) solution of water and household bleach. Then, immediately rinse the cleaned area with fresh water and wipe dry with a clean cloth.

Healthcare Wipes: Juggernaut, Nappa and Stipple are all approved for all healthcare wipes. Water rinse is still mandated for the patient's well-being as well as the longevity of the furniture. Juggernaut is also resistant to quaternary, phenol and ammonia-based chemical cleaners; extensive internal testing shows that Juggernaut stands up to many of these common cleaners and disinfectants.

Difficult Stains (Eye Shadow/Mascara, Lipstick, Crayon, Grease, Mustard):

Option 1: Clean the soiled area with a 20% (5:1) solution of water and household bleach. Then, immediately rinse the cleaned area with fresh water and wipe dry with a clean cloth.

Option 2: Clean the soiled area with a 50% solution of isopropyl alcohol (rubbing alcohol). Then, immediately rinse the cleaned area with fresh water and wipe dry with a clean cloth.

Ink Stains (Ballpoint Pen, Permanent Marker, Paint): Rub the marked area with undiluted isopropyl alcohol (rubbing alcohol). Then, immediately rinse the cleaned area with fresh water promptly after applying the alcohol. NOTE: It is not guaranteed that ink stains can be removed. To achieve best results, it is recommended to clean the stain immediately.

NOTE: If water or cleaning agent is left to sit on this material, it may leave a white residue/stain. It is important to rinse and wipe the material dry immediately after cleaning.

To achieve the best results in all cases, it is recommended that the stain be cleaned immediately.

The information in this polyurethane cleaning guide refers to performance in specific tests under laboratory conditions. This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.

VINYL VS. POLYURETHANE

	VINYL (POLYVINYL CHLORIDE)	POLYURETHANE		
CONTENT	Synthetic Plastic Polymer	PVC-free, more environmentally friendly		
MARKET	Commonly used across multiple market applications; healthcare is primary marketplace for vinyl due to cleaning requirements*	Commonly used across multiple market applications		
WEIGHT	28-30 oz./linear yard	14-20 oz./linear yard		
PLIABILITY	Stiffer hand	Softer and more supple hand		
UPHOLSTERABILITY	Minimal stretch creates greater difficulty with the upholstery process	Higher degree of stretch and recovery allows for a greater range of upholstery application		
RESISTANCE	Inherent stain and moisture resistance	Inherent stain and moisture resistance		
HYDROLYSIS (process in which humidity and heat deteriorate the cell structure of the material, resulting in a flaky or brittle surface) Resistant - vinyl cannot hydrolysize		Accelerated hydrolysis process when subjected to ongoing use of hard surface cleaners		

^{*}All materials, if exposed to hard surface cleaners, will break down at a more accelerated rate than if maintained using the proper cleaning instructions. If healthcare institutions regularly use hard surface cleaners, it's recommended to select a vinyl material based on a historical understanding that vinyl does not break down at the same rate as a polyurethane material. The textile industry continues to recommend the following general cleaning guidelines:

- General Cleaning
- Water Wipe
- Soap & Water with Rinse
- Disinfecting
- 10:1 Water/Bleach Mix with a Clean Water Rinse (Recommended by the CDC)

CUBICLES

Regular Maintenance: Machine wash with mild soap or detergent, on a synthetic setting with high water levels and mild agitation, temperature should not exceed 160°F. Do not use bleach or fabric softener. Wash with like materials. Extract gently.

Air, Cabinet, or tumble dry on a synthetic cycle at a low temperature. Do not excel 140°F for more that 3-5 minutes. Hang or fold immediately after drying.

If necessary, press as follows: Hand Iron: Iron at low setting (275°F) with a damp press cloth or steam iron with a dry press cloth. Grid Head Press: Press for short intervals and with minimum steam. Do not lock head. Flat Bed Press: Press dampened drapery using a cloth covering.

Avoid prolonged contact with heat.

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

FINISH-SPECIFIC CLEANING

CRYPTONS

To safely clean Crypton fabric, follow the manufacturer's recommended instructions. As with all cleaners, the fabric must be rinsed thoroughly.

For some specific healthcare concerns, such a C Difficile, a spore that requires bleach cleaning, the CDC (Center for Disease Control) instructions require a 10 percent bleach, 90 percent water mixture to effectively kill the growth. Any 100% polyester Crypton will safely withstand such cleaning, and there will not be any color loss after allowing the mixture to remain on the surface for the required 10-minute dwell time. Simply rinse the solution after cleaning using standard extraction equipment. Bleach cleaning, or bleach accidents will never affect the Crypton barrier, but some fibers that are cellulosic like rayon can encounter color loss quickly when they come into contact with bleach. http://www.cryptoncare.com/bleachcleanable.

RESILIENCE

Resilience^{SR} represents the latest technology in faux leather and vinyl protection, enhancing performance where it is needed the most.

Prompt cleaning is always recommended. Recommended cleaning steps are listed by type of stain. For best results, follow cleaning steps in order.

Recommended Care and Cleaning Steps

- Step 1: Mild soap and water, then rinse with fresh water and wipe dry with a clean cloth.
- Step 2: Wipe affected area with a soft cloth or soft bristle brush then continue with step 1.
- Step 3: 10% solution of household bleach and water. Rinse with fresh water and wipe dry.
- Step 4: 25% solution of alcohol and water. Rinse with fresh water and wipe dry.
- Step 5: 25% solution of lighter fluid or nail polish remover and water. Rinse with fresh water and wipe dry.

REGULAR CLEANING AND MAINTENANCE: STEP 1 Dirt Grime Dust	HEALTHCARE: STEPS 1, 2 AND 3 Betadine Urine Blood
OILS (ORGANIC & PETROLEUM BASED): STEPS 1 AND 2 Chocolate Ketchup Coffee Tea Juice	DIFFICULT STAINS: STEPS 1, 2, 3, 4 AND 5 Crayon Lipstick Eye Shadow/Mascara Mustard Grease Pain Ink/Permanent Marker

Note: The use of commercial vinyl conditioners and protectants is NOT RECOMMENDED.

The information in this cleaning guide refers to performance of ResilienceSM in tests conducted under laboratory conditions. This information does not imply a specific guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.

STA-KLEEN

DAY-TO-DAY CLEANING: Remove ordinary dirt and smudges with mild soap and water. Dry with a soft, lint-free cloth or towel. The use of conditioners or protectants is not required, nor recommended, for use on Sta-Kleen upholstery -- its cleanability is permanent and won't wear out.

DISINFECTING: A 5:1 ratio of water to bleach solution may be used as a disinfectant. Rinse the surface with clean water after disinfecting. Dry with a soft, lint-free cloth or towel.

STAIN REMOVAL: Upholstery protected with Sta-Kleen is resistant to most common stains. To keep your furniture looking new, stains such as ballpoint pen can be dry-erased with a clean, lint-free cloth. Gently rub the area until the stain has been removed. Wet or gooey stains such as food stains (e.g., ketchup) or topical stains (e.g., antiseptics, lotions and creams) should first be wiped off with a clean cloth or sponge, then follow the instructions above.

STUBBORN STAINS: If a ghost stain remains, apply a small amount of household rubbing alcohol (91% isopropyl alcohol) to a clean, lint-free cloth and rub the stain until it has been removed. Rinse with a clean, damp cloth and go!

CHEMICAL CLEANERS: High-performance construction creates significantly greater resistance to chemical cleaners, hence is approved for all common healthcare wipes. It is imperative that when these chemical cleaners are used that they are rinsed off with a wet sponge or damp cloth.

UPHOLSTERY CLEANING CODES (BY PATTERN)

HINT

WS

SANDSTONE

WS

UPHOLSTERY	CLEANING CODE	UPHOLSTERY	CLEANING CODE	UPHOLSTERY	CLEANING CODE
ADELE	WS	HOLY COW	WS	SELVEDGE	S
ALEA	WS	HOLY COW TOO	WS	SHEAR	WS
ALLURE	S	ICON	WS	SHERLOCK	S
ALLUSION	WS	IMBUE	WS	SHIFT	WS
AMARI	W	INFINITE HELIX	W	SIMILE	WS
AMPLE	WS	INLAY	S	SISAL	WS
APHRODITE	WS	IOTA	WS	SONNET	WS
ARC	WS	JAUNT	W	SPONTANEOUS	WS
ARCH	W	JET SET	WS	SPOT ON	WS
ARCHETYPE	WS	JUGGERNAUT	WS	STIPPLE	WS
ARJUNA	WS	KWAART	W	STIPPLING	S
ARTEMIS	WS	LATTICE	WS	STITCH	W
ASHA	W	LE FLEUR	W	SUJI STRIPE	WS
ASYMMETRIC	S	LINE	WS	SURFACE	WS
AWE	S	LORE	W	SWAY	W
AXIS	WS	LOUVER	S	TABOO	S
BALLAD	WS	LULL	W	TARTAN	WS
BASKET	W	LUMIERE	WS	TECH	W
BEDFORD	S	LYRIC	WS	TERRA	WS
BEND	WS	MAGIQUE	WS	TESSELLATION	WS
BONNAROO	W	MARBLES	WS	THREADS	WS
BOUNCE	WS	MARRAKESH EXPRESS	S	TILT	WS
BRIO	W	MERGE	S	TRANSLATION	WS
BROGUE	WS	MESH	W	TRAPUNTO	S
BURNISH	WS	METAPHOR	WS	TREK	WS
CHIC	WS	MIX	S	TRELLIS	WS
CHITRA	S	MOD	WS	TULIPS	W
COCO	S	MODE	WS	TWINE	WS
COMPOSITION	S	MODERN BLAZE	WS	UNRAVELED	WS
CONSTRUCT	S	MOSAIC	WS	UNSPUN	W
CRAFT	WS	MOTTO	WS	URBANIZED	WS
CURIO	W	MYSTERE	WS	UTOPIA	S
CYBELE	WS	NAP	WS	VEER	W
	WS	NAPPA	WS	VERSE	WS
DECKED OUT DEEPLY ROOTED	WS	NEO	S	VERTICES	WS
DEFLECT	WS	NIGHT CAP	WS	VESPA	S
DÉJÀ VU		NOMAD	WS	VIGNETTE	WS
	WS			WANDER	
DEMETER	WS	NUANCE ODE	WS		WS
DEMI	W		WS	WEST BENGAL	S
DRIFT	WS	OOH LA LANA	S		
EDGE	WS	ORIGIN	WS		
ESSENCE	WS	PANACHE	WS		
ETCH	WS	PATAGONIA	S		
ETHOS	WS	PATINA	WS		
FLOW	WS	PERCEPTION	S		
FLUX	WS	PETALS	S		
FOLIE	WS	PHENOMENA	S		
FRACTURE	W	PINCH PLEAT	WS		
FRESH	WS	PIVOT	WS		
FRIEZE	WS	PLUSH	WS		
FUSE	WS	POLKA DOTTY	WS		
GATHER	WS	POPCORN	WS		
GENE POOL	S	POSH	WS		
GLAM	WS	PROMENADE	W		
GLITZ	WS	PROSE	WS		
GRAPH	WS	PURL	WS		
GRILLE	S	REFLECTION	WS		
GROOVE	WS	REVEL	WS		
HALFTONE	WS	REVERIE	WS		
HARMONY	S	ROGUE	WS		
HAVEN	WS	ROUND	WS		
HEARTH	WS	ROVE	W		

UPHOLSTERY CLEANING CODES (BY CODE)

UPHOLSTERY	'S' CLEANING CODE	UPHOLSTERY	'WS' CLEANING CODE	UPHOLSTERY	'WS' CLEANING COD
ALLURE	S	ADELE	WS	NOMAD	WS
ASYMMETRIC	S	ALEA	WS	NUANCE	WS
AWE	S	ALLUSION	WS	ODE	WS
BEDFORD	S	AMPLE	WS	ORIGIN	WS
CHITRA	S	APHRODITE	WS	PANACHE	WS
coco	S	ARC	WS	PATINA	WS
COMPOSITION	S	ARCHETYPE	WS	PINCH PLEAT	WS
CONSTRUCT	S	ARJUNA	WS	PIVOT	WS
					WS
GENE POOL	S	ARTEMIS	WS	PLUSH	
GRILLE	S	AXIS	WS	POLKA DOTTY	WS
HARMONY	S	BALLAD	WS	POPCORN	WS
INLAY	S	BEND	WS	POSH	WS
LOUVER	S	BOUNCE	WS	PROSE	WS
MARRAKESH EXPRESS	S	BROGUE	WS	PURL	WS
MERGE	S	BURNISH	WS	REFLECTION	WS
MIX	S	CHIC	WS	REVEL	WS
NEO	S	CRAFT	WS	REVERIE	WS
OOH LA LANA	S	CYBELE	WS	ROGUE	WS
				ROUND	
PATAGONIA	S	DECKED OUT	WS		WS
PERCEPTION	S	DEEPLY ROOTED	WS	SANDSTONE	WS
PETALS	S	DEFLECT	WS	SHEAR	WS
PHENOMENA	S	DÉJÀ VU	WS	SHIFT	WS
SELVEDGE	S	DEMETER	WS	SIMILE	WS
SHERLOCK	S	DRIFT	WS	SISAL	WS
STIPPLING	S	EDGE	WS	SONNET	WS
TABOO	S	ESSENCE	WS	SPONTANEOUS	WS
TRAPUNTO	S	ETCH	WS	SPOT ON	WS
	S	ETHOS		STIPPLE	WS
UTOPIA			WS		
VESPA	S	FLOW	WS	SUJI STRIPE	WS
WEST BENGAL	S	FLUX	WS	SURFACE	WS
		FOLIE	WS	TARTAN	WS
		FRIEZE	WS	TERRA	WS
		FUSE	WS	TESSELLATION	WS
		GATHER	WS	THREADS	WS
		GLAM	WS	TILT	WS
		GLITZ	WS	TRANSLATION	WS
		GRAPH	WS	TREK	WS
UPHOLSTERY	'W' CLEANING CODE				WS
AMARI	W	GROOVE	WS	TRELLIS	
ARCH	W	HALFTONE	WS	TWINE	WS
ASHA	W	HAVEN	WS	UNRAVELED	WS
BASKET		HEARTH	WS	URBANIZED	WS
	W	HINT	WS	VERSE	WS
BONNAROO	W	HOLY COW	WS	VERTICES	WS
BRIO	W	HOLY COW TOO	WS	VIGNETTE	WS
CURIO	W	ICON	WS	WANDER	WS
DEFLECTION	W	IMBUE	WS		
DEMI	W	IOTA	WS		
FRACTURE	W	JET SET			
FRESH	W		WS		
INFINITE HELIX	W	JUGGERNAUT	WS		
JAUNT	W	LATTICE	WS		
		LINE	WS		
KWAART	W	LUMIERE	WS		
LE FLEUR	W	LYRIC	WS		
LORE	W	MAGIQUE	WS		
LULL	W	MARBLES	WS		
MESH	W	METAPHOR	WS		
PROMENADE	W	MOD	WS		
ROVE	W				
STITCH	W	MODE MODERNI DI AZE	WS		
SWAY	W	MODERN BLAZE	WS		
	W	MOSAIC	WS		
TECH		MOTTO	WS		
	W	MYSTERE	WS		
TULIPS UNSPUN	W	NAP	WS		
	W W	NAP NAPPA	WS WS		

