


Left Side of the Chair:

1. **Tilt Tension** - To increase back tension, turn the dial under the front center of the seat clockwise; counter-clockwise to decrease back tension.
2. **Front Seat Tilt** - To allow the seat to tilt forward, lean back slightly and simultaneously push the lever down. To lock-out the tilting front seat, lean back and pull the lever up.
Note: To do the above, the back angle lock lever must be down.
3. **Seat Slide** - Push up on the button and simultaneously move the seat in or out.



Right Side of the Chair:

1. **Seat Height** - To lower seat height, pull up on the lever. To raise seat height, lift your weight off of the seat and simultaneously pull up on the lever.
2. **Back Angle Lock** - To lock the back in one of three angles, pull up on the lever while at the desired angle. To allow the back to "free-float", lean back slightly and push the lever down.
3. **Back Height** - To raise or lower back height, pull the lever at the bottom right side of the back and simultaneously raise or lower the back.

