


6C

## KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3  
tel 416 759 5665 fax 416 759 5723 1 800 724 5665  
[www.keilhauer.com](http://www.keilhauer.com) [info@keilhauer.com](mailto:info@keilhauer.com)

## 1. Seat Height Adjustment (while seated)



Use this  
(to raise or  
lower seat)

**Use** the lever on the right side underneath the seat.

**To raise** lift your weight off the seat while lifting the front of the lever.

**To lower** sit on the seat while lifting the front of the lever.

Knee Tilt (optional feature)

## 2. Tilt Tension

Use this  
(to increase or  
decrease  
tension)




**Use** the big round knob underneath the center of the seat.

**To increase** tension turn the knob clockwise.

**To decrease** tension turn the knob counter-clockwise.

Knee Tilt (optional feature)

### 3. Tilt Lock (while seated)



**Use** the paddle shaped lever on the left side underneath the seat.

**To unlock tilt** pull the front of the lever up and tilt back slightly.

**To lock tilt** recline to your desired position and push the front of the lever down.

#### 4. Arm Height Adjustment (optional feature)



**Use** the buttons underneath the arm rests.

**To raise or lower** push the button in and raise or lower the arm rest and release button to lock.

## 5. Lumbar Adjustment (optional feature)

Use this  
(to adjust lumbar)



**Use** the handles on either side of the back.

**To raise or lower** grasp both handles and slide the lumbar support to the desired position.

