


# Sway Mid Back

KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3  
tel 416 759 5665 fax 416 759 5723 1 800 724 5665  
[www.keilhauer.com](http://www.keilhauer.com) [info@keilhauer.com](mailto:info@keilhauer.com)

## 1. Seat Height Adjustment (while seated)




Use this  
(to raise or  
lower seat)

**Use** the paddle shaped lever on the left side underneath the seat  
**To raise** lift your weight off the seat while lifting the front of the lever  
**To lower** sit on the seat while lifting the front of the lever

## 2. Tilt Tension

## 3. Tilt Lock (while seated)



Use this  
(to increase or  
decrease tension)

Use this  
(to lock or unlock  
backward tilt)

**Use** the adjustment knob at the end of the height adjustment lever

**To increase** tension slide the knob out and turn the knob clockwise. Slide knob back into place.

**To decrease** tension slide the knob out and turn the knob counter-clockwise. Slide knob back into place.

**Use** the paddle shaped lever on the right side underneath the seat

**To unlock tilt** pull the front of the lever up and tilt back slightly

**To lock tilt** recline to your desired position and push the front of the lever down