

Unity


KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3
tel 416 759 5665 fax 416 759 5723 1 800 724 5665
www.keilhauer.com info@keilhauer.com

Sit down. Please.

The only way to know if you are adjusting your chair to provide you with maximum comfort, is to make these adjustments while you are seated.


6. Arm Adjustment (optional feature)



To rotate grasp the front of the arm rest firmly and pivot the arm cap inwards or outwards

1. Seat Height Adjustment (while seated)

2. Back Height



Use the paddle shaped lever on the right side underneath the seat

To raise lift your weight off the seat while lifting the front of the lever

To lower sit on the seat while lifting the front of the lever


Use the sides of the back just above the seat and grab with both hands

To raise the back lift the back up and towards you - you will hear a click for each different height

To lower lift the back to the highest setting and it will disengage allowing it to drop down to the starting (lowest) height; the back must return to the starting position to reengage the height adjustment mechanism

3. Tilt Tension

4. Tilt Lock (while seated)




Use the adjustment knob at the end of the height adjustment lever
To increase tension slide the knob out and turn the knob clockwise.
Slide knob back into place.

To decrease tension slide the knob out and turn the knob counter-clockwise. Slide knob back into place.

Use the paddle shaped lever on the left side underneath the seat
To unlock tilt pull the front of the lever up and tilt back slightly
To lock tilt recline to your desired position and push the front of the lever down

5. Arm Height Adjustment (optional feature)



Use the buttons underneath the arm rests

To raise or lower push the button in and raise or lower the arm rest and release button to lock

