

Vanilla


KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3
tel 416 759 5665 fax 416 759 5723 1 800 724 5665
www.keilhauer.com info@keilhauer.com

Sit down. Please.

The only way to know if you are adjusting your chair to provide you with maximum comfort, is to make these adjustments while you are seated.

1. Seat Height Adjustment




Use the lever on the right side underneath the seat.

To raise lift your weight off the seat while lifting the front of the lever.

To lower sit on the seat while lifting the front of the lever.

2. Tilt




Use the big round knob underneath the center of the seat.

To increase tension turn the knob clockwise.

To decrease tension turn the knob counter-clockwise.

3. Tilt Lock



Use the paddle shaped lever on the left side underneath the seat.
To unlock tilt pull the front of the lever up and tilt back slightly.
To lock tilt recline to your desired position and push the front of the lever down.

