

KI (Krueger International)  
1330 Bellevue St.  
P.O. Box 8100  
Green Bay, WI 54308-8100

"Customer Focused, Quality Driven"  
Fixed Seating      Phone: 414-468-2744  
Fax: 414-468-2725

## **Memo**

**TO:**

**FROM:**

**RE:            Replacement springs on University seats**

Following are the directions to change out the old style springs with the updated springs.

The 45-0080-B spring replaces the 45-0080-A spring. If your product has the A spring, it may be necessary to drill two holes to attach the B spring.

Remove the 2 screws on the coverplate with 9/16" wrench.  
Using needle nose plyers grab & twist the springs to remove.  
Holes need to be drilled if your product was installed prior to 1989.

After drilling two holes per diagram following, attach the springs in the same manner as removed. If the springs cannot be attached this way, using an allen head wrench, loosen the two lockwashers & hex nut at bottom of box, this allows the swing arm to come out.

If you have any questions, please give me a call.

Fixed Seating Product Coordinator