



PALLAS

MAINTENANCE & CLEANING

TABLE OF CONTENTS

- 1 Upholstery
- 2 Yarns
- 3 Polyurethane
- 4 Vinyl vs. Polyurethane
- 5 Cubicles
- 6 Finish-Specific Cleaning
- 7 Cleaning Codes (By Pattern)
- 8 Cleaning Codes (By Code)

UPHOLSTERY MAINTENANCE AND CLEANING INFORMATION

UPHOLSTERY

- W** Clean only with water-based shampoo or foam upholstery cleaner. Do not over wet. Do not use dry cleaning solvents to spot clean. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and laundered.
- S** Clean only with dry cleaning solvent. Do not saturate. Do not use water. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and dry cleaned.
- WS** Clean with mild detergent or shampoo, foam or dry cleaning solvent as desired. Do not saturate with liquid. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and dry cleaned or laundered.
- X** Do not clean with either water or solvent-based cleaner. Use vacuuming or light brushing only.

Water based cleaning agents* are often classified as upholstery shampoo. They are usually commercially available as foams, concentrates and dry components.

Cleaning can be either wet or dry, though some suggest a third category, damp.

Wet cleaning equipment using water is classified into two broad types:
Rotary or hand-applied shampoo
Water extraction (sometimes inaccurately referred to as a steam cleaning)

Two of the damp processes with water are:
Dry foam
Rotary mop (bonnet)

Dry systems use a granule or powder that incorporates a cleaning solvent or a non-water chemical solvent, which allows soil to be removed by subsequent vacuuming.

Pre-test your cleaning method on an inconspicuous area of the fabric to determine if color bleeds, shrinks the fabric texture or alters the character. If there is any doubt, seek the assistance of a professional cleaning service.

* Examples include *Glamorene, Glory, Blue Lustre and Woolite.*

UPHOLSTERY MAINTENANCE AND CLEANING INFORMATION

YARNS

BELLA DURA

Bella-Dura fabrics are inherently stain resistant, so a mild soap and water solution is all that is needed to remove most stains. Any cleaning product that can be used on indoor/outdoor fabrics is safe to use on Bella-Dura® as well as bleach for tough stains. Always rinse with clean water and allow to air dry. Take care when mixing cleaners with bleach and work in a well ventilated area. Bella-Dura® fabrics are woven with fibers that dry easily; Bella-Dura® fabrics should always be air-dried and never tumble-dried.

©Bella-Dura is a registered trademark of Wearbest Sil-Tex Mills, Ltd.

PILE/CHENILLE

Regular care (weekly)

- Vacuum regularly using low suction
- Rotate reversible cushions regularly
- Protect from direct sunlight

Pilling can occur occasionally as a result of normal daily wear and should not be considered as a fault. Fibre pills can be removed by a battery operated pilling tool available from most haberdashery stores.

Q2 POLYESTER

Lyric uses Q2 yarns, which are OEKO-TEX® 100 certified and rigorously tested down to each individual color as each perform differently.

Q2 high-performance yarns give textiles the following attributes:

- Superior durability
- High abrasion resistance
- High light fastness values
- Free from chemical additives (conforms to Prop 65, AB 2998 and is free from FR chemicals)
- Skin safe and hypo-allergenic
- Easy to clean and bleach cleanable (most stains can be removed with simple soap and water; solvent-based stains such as permanent marker can be removed with acetone)
- Easy to disinfect (use household disinfectant products)

UPHOLSTERY MAINTENANCE AND CLEANING INFORMATION

POLYURETHANE

Regular Cleaning and Maintenance (Dirt, Dust, Grime): Clean the soiled area with mild soap and water, then immediately rinse the surface with fresh water and wipe dry with a clean cloth.

Food Stains/Oils (Ketchup, Chocolate, Coffee, Tea, Juice): Wipe affected area with a soft cloth or sponge, then follow the regular cleaning and maintenance above.

Healthcare Disinfecting: Clean the area with the CDC-approved 10:1 water and household bleach mixture. Then, immediately rinse the disinfected area with fresh water and wipe dry with a clean cloth.

Healthcare Stains (Blood, Urine, Betadine, Disinfectant): Clean the soiled area with a 20% (5:1) solution of water and household bleach. Then, immediately rinse the cleaned area with fresh water and wipe dry with a clean cloth.

Healthcare Wipes: Juggernaut, Nappa and Stipple are all approved for all healthcare wipes. Water rinse is still mandated for the patient's well-being as well as the longevity of the furniture. Juggernaut is also resistant to quaternary, phenol and ammonia-based chemical cleaners; extensive internal testing shows that Juggernaut stands up to many of these common cleaners and disinfectants.

Difficult Stains (Eye Shadow/Mascara, Lipstick, Crayon, Grease, Mustard):

Option 1: Clean the soiled area with a 20% (5:1) solution of water and household bleach. Then, immediately rinse the cleaned area with fresh water and wipe dry with a clean cloth.

Option 2: Clean the soiled area with a 50% solution of isopropyl alcohol (rubbing alcohol). Then, immediately rinse the cleaned area with fresh water and wipe dry with a clean cloth.

Ink Stains (Ballpoint Pen, Permanent Marker, Paint): Rub the marked area with undiluted isopropyl alcohol (rubbing alcohol). Then, immediately rinse the cleaned area with fresh water promptly after applying the alcohol. NOTE: It is not guaranteed that ink stains can be removed. To achieve best results, it is recommended to clean the stain immediately.

NOTE: If water or cleaning agent is left to sit on this material, it may leave a white residue/stain. It is important to rinse and wipe the material dry immediately after cleaning.

To achieve the best results in all cases, it is recommended that the stain be cleaned immediately.

The information in this polyurethane cleaning guide refers to performance in specific tests under laboratory conditions. This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.

UPHOLSTERY MAINTENANCE AND CLEANING INFORMATION

VINYL VS. POLYURETHANE

	VINYL (POLYVINYL CHLORIDE)	POLYURETHANE
CONTENT	Synthetic Plastic Polymer	PVC-free, more environmentally friendly
MARKET	Commonly used across multiple market applications; healthcare is primary marketplace for vinyl due to cleaning requirements*	Commonly used across multiple market applications
WEIGHT	28-30 oz./linear yard	14-20 oz./linear yard
PLIABILITY	Stiffer hand	Softer and more supple hand
UPHOLSTERABILITY	Minimal stretch creates greater difficulty with the upholstery process	Higher degree of stretch and recovery allows for a greater range of upholstery application
RESISTANCE	Inherent stain and moisture resistance	Inherent stain and moisture resistance
HYDROLYSIS <small>(process in which humidity and heat deteriorate the cell structure of the material, resulting in a flaky or brittle surface)</small>	Resistant – vinyl cannot hydrolysize	Accelerated hydrolysis process when subjected to ongoing use of hard surface cleaners

*All materials, if exposed to hard surface cleaners, will break down at a more accelerated rate than if maintained using the proper cleaning instructions. If healthcare institutions regularly use hard surface cleaners, it's recommended to select a vinyl material based on a historical understanding that vinyl does not break down at the same rate as a polyurethane material. The textile industry continues to recommend the following general cleaning guidelines:

- General Cleaning
 - Water Wipe
 - Soap & Water with Rinse
- Disinfecting
 - 10:1 Water/Bleach Mix with a Clean Water Rinse (Recommended by the CDC)

UPHOLSTERY MAINTENANCE AND CLEANING INFORMATION

CUBICLES

Regular Maintenance: Machine wash with mild soap or detergent, on a synthetic setting with high water levels and mild agitation, temperature should not exceed 160°F. Do not use bleach or fabric softener. Wash with like materials. Extract gently.

Air, Cabinet, or tumble dry on a synthetic cycle at a low temperature. Do not exceed 140°F for more than 3-5 minutes. Hang or fold immediately after drying.

If necessary, press as follows: Hand Iron: Iron at low setting (275°F) with a damp press cloth or steam iron with a dry press cloth. Grid Head Press: Press for short intervals and with minimum steam. Do not lock head. Flat Bed Press: Press dampened drapery using a cloth covering.

Avoid prolonged contact with heat.

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

UPHOLSTERY MAINTENANCE AND CLEANING INFORMATION

FINISH-SPECIFIC CLEANING

CRYPTONS

To safely clean Crypton fabric, follow the manufacturer’s recommended instructions. As with all cleaners, the fabric must be rinsed thoroughly.

For some specific healthcare concerns, such as C Difficile, a spore that requires bleach cleaning, the CDC (Center for Disease Control) instructions require a 10 percent bleach, 90 percent water mixture to effectively kill the growth. Any 100% polyester Crypton will safely withstand such cleaning, and there will not be any color loss after allowing the mixture to remain on the surface for the required 10-minute dwell time. Simply rinse the solution after cleaning using standard extraction equipment. Bleach cleaning, or bleach accidents will never affect the Crypton barrier, but some fibers that are cellulosic like rayon can encounter color loss quickly when they come into contact with bleach. <http://www.cryptoncare.com/bleachcleanable>.

RESILIENCE

Resilience^{SR} represents the latest technology in faux leather and vinyl protection, enhancing performance where it is needed the most.

Prompt cleaning is always recommended. Recommended cleaning steps are listed by type of stain. For best results, follow cleaning steps in order.

Recommended Care and Cleaning Steps

Step 1: Mild soap and water, then rinse with fresh water and wipe dry with a clean cloth.

Step 2: Wipe affected area with a soft cloth or soft bristle brush then continue with step 1.

Step 3: 10% solution of household bleach and water. Rinse with fresh water and wipe dry.

Step 4: 25% solution of alcohol and water. Rinse with fresh water and wipe dry.

Step 5: 25% solution of lighter fluid or nail polish remover and water. Rinse with fresh water and wipe dry.

REGULAR CLEANING AND MAINTENANCE: STEP 1 Dirt Dust Grime	HEALTHCARE: STEPS 1, 2 AND 3 Betadine Blood Urine
OILS (ORGANIC & PETROLEUM BASED): STEPS 1 AND 2 Chocolate Coffee Juice Ketchup Tea	DIFFICULT STAINS: STEPS 1, 2, 3, 4 AND 5 Crayon Eye Shadow/Mascara Grease Ink/Permanent Marker Lipstick Mustard Pain

Note: The use of commercial vinyl conditioners and protectants is NOT RECOMMENDED. The information in this cleaning guide refers to performance of ResilienceSM in tests conducted under laboratory conditions. This information does not imply a specific guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and referenced cleaning agents.

STA-KLEEN

DAY-TO-DAY CLEANING: Remove ordinary dirt and smudges with mild soap and water. Dry with a soft, lint-free cloth or towel. The use of conditioners or protectants is not required, nor recommended, for use on Sta-Kleen upholstery -- its cleanability is permanent and won't wear out.

DISINFECTING: A 5:1 ratio of water to bleach solution may be used as a disinfectant. Rinse the surface with clean water after disinfecting. Dry with a soft, lint-free cloth or towel.

STAIN REMOVAL: Upholstery protected with Sta-Kleen is resistant to most common stains. To keep your furniture looking new, stains such as ballpoint pen can be dry-erased with a clean, lint-free cloth. Gently rub the area until the stain has been removed. Wet or gooey stains such as food stains (e.g., ketchup) or topical stains (e.g., antiseptics, lotions and creams) should first be wiped off with a clean cloth or sponge, then follow the instructions above.

STUBBORN STAINS: If a ghost stain remains, apply a small amount of household rubbing alcohol (91% isopropyl alcohol) to a clean, lint-free cloth and rub the stain until it has been removed. Rinse with a clean, damp cloth and go!

CHEMICAL CLEANERS: High-performance construction creates significantly greater resistance to chemical cleaners, hence is approved for all common healthcare wipes. It is imperative that when these chemical cleaners are used that they are rinsed off with a wet sponge or damp cloth.

UPHOLSTERY CLEANING CODES (BY PATTERN)

UPHOLSTERY	CLEANING CODE	UPHOLSTERY	CLEANING CODE	UPHOLSTERY	CLEANING CODE
ADELE	WS	GRAPH	WS	PERCEPTION	S
AHTI	WS	GRILLE	S	PETALS	S
ALEA	WS	GROOVE	WS	PHENOMENA	S
ALLURE	S	HALFTONE	WS	PINCH PLEAT	WS
ALLUSION	WS	HALI	WS	PLUSH	WS
AMARI	W	HARMONY	S	POLKA DOTTY	WS
AMPLE	WS	HAVEN	WS	POPCORN	WS
APHRODITE	WS	HEARTH	WS	POSH	WS
ARC	WS	HINT	WS	PROMENADE	W
ARCH	W	HOLY COW	WS	PROSE	WS
ARCHETYPE	WS	HOLY COW TOO	WS	PURL	WS
ARJUNA	WS	HUE	W	REFLECTION	WS
ARRAY	W	ICON	WS	REVEL	WS
ARTEMIS	WS	IMBUE	WS	REVERIE	WS
ASHA	W	INLAY	S	ROGUE	WS
AUBE	WS	IOTA	WS	ROUND	WS
BALLAD	WS	ISLA	WS	ROVE	W
BASKET	W	JAUNT	W	SANDSTONE	WS
BEDFORD	S	JET SET	WS	SELVEDGE	S
BEND	WS	JUGGERNAUT	WS	SHEAR	WS
BOUNCE	WS	KAI	WS	SHERLOCK	WS
BRIO	W	KWAART	W	SHIFT	WS
BROGUE	WS	LATTICE	WS	SIMILE	WS
BRUME	WS	LE FLEUR	W	SISAL	WS
BURNISH	WS	LINE	WS	SOLSTICE	WS
CHAMBRAY	WS	LLYR	WS	SONNET	WS
CHIC	WS	LORE	W	SPONTANEOUS	WS
CHITRA	S	LULL	W	SPOT ON	WS
CHROMA	WS	LUMEN	WS	STIPPLE	WS
CIEL	WS	LUMIERE	WS	STIPLING	S
COCO	S	LYRIC	WS	STITCH	W
COMPOSITION	S	MAGIQUE	WS	SUJI STRIPE	WS
CONSTRUCT	S	MARBLES	WS	SURFACE	WS
CRAFT	WS	MAREN	WS	SWAY	W
CURIO	W	MARRAKESH EXPRESS	S	TABOO	S
CYBELE	WS	MATKA	WS	TARTAN	WS
DECKED OUT	WS	MERGE	S	TECH	W
DEFLECT	WS	MESH	W	TERRA	WS
DÉJÀ VU	WS	METAPHOR	WS	TESSELLATION	WS
DEMETER	WS	MIX	S	THREADS	WS
DEMI	W	MOD	WS	TILT	WS
DRIFT	WS	MODE	WS	TOILE	WS
DUNE	WS	MODERN BLAZE	WS	TRANSLATION	WS
ECHO	WS	MONET	WS	TRAPUNTO	S
EDGE	WS	MONSOON	WS	TREK	WS
ESSENCE	WS	MOSAIC	WS	TRELLIS	WS
ETCH	WS	MOTTO	WS	TULIPS	W
ETHOS	WS	MYSTERE	WS	TWINE	WS
FACET	WS	NAP	WS	UNRAVELED	WS
EVER	WS	NAPPA	WS	UNSPUN	W
FLOW	WS	NIGHT CAP	WS	URBANIZED	WS
FLUX	WS	NOMAD	WS	UTOPIA	S
FOLIE	WS	NUANCE	WS	VALE	WS
FRACTURE	W	NYMPHEA	WS	VEER	W
FRESH	W	ODE	WS	VERSE	WS
FRIEZE	WS	OOH LA LANA	S	VERTICES	WS
FUSE	WS	ORIGIN	WS	VESPA	S
GLAM	WS	PANACHE	WS	VIGNETTE	WS
GLINT	WS	PATAGONIA	S	WANDER	WS
GLITZ	WS	PATINA	WS	WEST BENGAL	S
				ZEPHYR	WS

UPHOLSTERY CLEANING CODES (BY CODE)

UPHOLSTERY	'S' CLEANING CODE	UPHOLSTERY	'WS' CLEANING CODE	UPHOLSTERY	'WS' CLEANING CODE
ALLURE	S	APHRODITE	WS	MATKA	WS
BEDFORD	S	ARC	WS	METAPHOR	WS
CHITRA	S	ARCHETYPE	WS	MOD	WS
COCO	S	ARJUNA	WS	MODE	WS
COMPOSITION	S	ARTEMIS	WS	MODERN BLAZE	WS
CONSTRUCT	S	AUBE	WS	MONET	WS
GRILLE	S	BALLAD	WS	MONSOON	WS
HARMONY	S	BEND	WS	MOSAIC	WS
INLAY	S	BOUNCE	WS	MOTTO	WS
MARRAKESH EXPRESS	S	BROGUE	WS	MYSTERE	WS
MERGE	S	BRUME	WS	NAP	WS
MIX	S	BURNISH	WS	NAPPA	WS
OOH LA LANA	S	CHAMBRAY	WS	NIGHT CAP	WS
PATAGONIA	S	CHIC	WS	NOMAD	WS
PERCEPTION	S	CHROMA	WS	NUANCE	WS
PETALS	S	CIEL	WS	NYMPHEA	WS
PHENOMENA	S	CRAFT	WS	ODE	WS
SELVEDGE	S	CYBELE	WS	ORIGIN	WS
STIPPLING	S	DECKED OUT	WS	PANACHE	WS
TABOO	S	DEFLECT	WS	PATINA	WS
TRAPUNTO	S	DÉJÀ VU	WS	PINCH PLEAT	WS
UTOPIA	S	DEMETER	WS	PLUSH	WS
VESPA	S	DRIFT	WS	POLKA DOTTY	WS
WEST BENGAL	S	DUNE	WS	POPCORN	WS
		ECHO	WS	POSH	WS
		EDGE	WS	PROSE	WS
		ESSENCE	WS	PURL	WS
		ETCH	WS	REFLECTION	WS
		ETHOS	WS	REVEL	WS
		EVER	WS	REVERIE	WS
		FACET	WS	ROGUE	WS
		FLOW	WS	ROUND	WS
		FLUX	WS	SANDSTONE	WS
		FOLIE	WS	SHEAR	WS
		FRIEZE	WS	SHERLOCK	WS
		FUSE	WS	SHIFT	WS
		GLAM	WS	SIMILE	WS
		GLINT	WS	SISAL	WS
		GLITZ	WS	SOLSTICE	WS
		GRAPH	WS	SONNET	WS
		GROOVE	WS	SPONTANEOUS	WS
		HALFTONE	WS	SPOT ON	WS
		HALI	WS	STIPPLE	WS
		HAVEN	WS	SUJI STRIPE	WS
		HEARTH	WS	SURFACE	WS
		HINT	WS	TARTAN	WS
		HOLY COW	WS	TERRA	WS
		HOLY COW TOO	WS	TESSELLATION	WS
		ICON	WS	THREADS	WS
		IMBUE	WS	TILT	WS
		IOTA	WS	TOILE	WS
		ISLA	WS	TRANSLATION	WS
		JET SET	WS	TREK	WS
		JUGGERNAUT	WS	TRELLIS	WS
		KAI	WS	TWINE	WS
		LATTICE	WS	UNRAVELED	WS
		LINE	WS	URBANIZED	WS
		LLYR	WS	VALE	WS
		LUMEN	WS	VERSE	WS
		LUMIERE	WS	VERTICES	WS
		LYRIC	WS	VIGNETTE	WS
		MAGIQUE	WS	WANDER	WS
		MARBLES	WS	ZEPHYR	WS
		MAREN	WS		
UPHOLSTERY	'W' CLEANING CODE				
AMARI	W				
ARCH	W				
ARRAY	W				
ASHA	W				
BASKET	W				
BRIO	W				
CURIO	W				
DEFLECTION	W				
DEMI	W				
FRACTURE	W				
FRESH	W				
HUE	W				
JAUNT	W				
KWAART	W				
LE FLEUR	W				
LORE	W				
LULL	W				
MESH	W				
PROMENADE	W				
ROVE	W				
STITCH	W				
SWAY	W				
TECH	W				
TULIPS	W				
UNSPUN	W				
VEER	W				
UPHOLSTERY	'WS' CLEANING CODE				
ADELE	WS				
AHTI	WS				
ALEA	WS				
ALLUSION	WS				
AMPLE	WS				



PALLAS