

Cleaning & Care Guidelines for Ultrafabrics® Products

Cleaning Guidelines

One of the best ways to keep Ultrafabrics, LLC brand surfaces looking great is to properly maintain them by cleaning regularly to prevent excessive dirt from accumulating. Below is a general outline to help you keep your quality Ultrafabrics brand products looking their best.

Following these guidelines will help to extend the life of the fabric:

- Clean regularly with soap and water
- Wipe up spills *as soon as they occur*
- Lift most stains with an alcohol-based cleaner like Fantastik® and Formula 409®
- Clean/disinfect using a 5:1 water/bleach solution or a commonly used healthcare disinfectant (listed below)
- Thoroughly rinse all solution residue with water
- Air dry

* Recommended for stubborn stains and/or mildew.

Disinfectants

Asepticare® TB + II, Birex®, CaviCide®, Clorox® Disinfecting Wipes, DisCide®, LYSOL® Disinfectant, Viraguard®, and Virox® Accel TB
When using these disinfectants, please follow instructions as directed on the label. We strongly recommend rinsing the surface with clean water in order to remove any residue.

This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and all cleaning agents. The use of certain agents can be harmful to the surface appearance and lifespan of the product if not used properly. Ultrafabrics assumes no responsibility resulting from improper use of the cleaning agents.

Care Guidelines for High UV

- **All** Ultrafabrics High UV products should be stored in a dry, well ventilated area
- Ultrafabrics mildew resistant surfaces do not promote mildew growth, however, mildew may grow on dirt and other foreign substances that are not removed from the fabric
- The frequency of cleaning will vary greatly depending upon the local outdoor environment in which the product is used
- Cushions should not remain wet or be covered, as this will increase the chances of mildew growth occurring

*All of our High UV products perform best when:

1. Paired with an open cell, reticulated, quick drying foam and/or a waterproof, anti-mildew barrier between the fabric and foam
2. Utilizing air vents and/or a mesh, open weave fabric bottom

*These recommendations allow for proper draining and quick drying.

Recommended Ballpoint Pen Removal Instructions

- Wipe the stain off with isopropyl (rubbing alcohol) as soon as possible
- Rinse with water
- Air dry

*While the foregoing instructions have proven to work in many cases, especially in which ink stains are addressed immediately, not all ink stains can be removed.

PLEASE NOTE: A variety of clothing and accessories may contain dyes that could transfer to lighter colors, depending upon variations in temperature and humidity. Dye transfer is difficult to control, not always fully preventable, and may be irreversible. Ultrafabrics, LLC assumes no responsibility and can not be held liable for dye transfer caused by external contaminants.

For more information, please visit us on the web at www.ultrafabricsllc.com