

INSTRUCTION BOOK FOR


Computer Table Laptop Storage Cart



A CAUTION! The user of this product should exercise caution when moving the cart. Any sudden stop could cause instability of the cart and could cause serious injury and/or damage. The cart should always be pushed, never pulled, by the user. Always push from the side of the cart, never from the front or back of the cart.


Required Tools:

-1/2" end wrench




Procedure

1. Remove contents from carton and examine.







Item	De	escription	Qty	Qty
1	Divider		16	24
2	Cart Assembly		1	1
3	Ca	ster, Plate 5" W/B	2	2
4	Caster, Plate 5"		2	2
5	Package Set		1	1
	Α	Grommet, 2"	8	8
	В	Bolt, HHCS 5/16"-18 x 3/4"	16	16
	С	Wrench, Allen 5/32"	1	1




Procedure (Continued)

- 2. Lay cart onto rear panel. See Figure 1. Using a 1/2" wrench, Install Plate Casters (3 & 4) using 5/16"-18 \times 3/4" Bolts (B). For maximum braking capacity, the two brake casters should be installed diagonally across from each other. Tighten all fasteners.
- 3. To disengage lock, insert and turn key 1/4 turn to the right. To open latch, push inward on chrome keypad.
- 4. Install the dividers as needed. Install grommets. See Figure 2.








Procedure (Continued)

5. Remove rear panel by removing the hex head screws using the 5/32" hex key (C). See Figure 3.


Note: CT-LS20 has (5) hex head screws and CT-LS30 has (8).






Note: If the cart was ordered as an assembly including power strips, a strip will be pre-installed on each shelf.

7. Reattach rear panel using the (8) hex head screws removed in the step 6. See Figure 3.







A Milestone AV Technologies Brand

3100 North Detroit Street Warsaw, Indiana 46582 P: 574.267.8101 or 800.622.3737 F: 574.267.7804 or 877.325.4832 E: info@da-lite.com www.da-lite.com