Cleaning Guide



Pattern: Contour

AC#: **62050 - 62063**

Content: 100% Vinyl Face/100% Polyester Hi-Loft^{2TM} Back


Bleach May be cleaned with bleach following the proper ratio of

Cleanable: 90% water: 10% bleach.

Finish: **PBG+**

Cleaning

Code: WS



General Cleaning Recommendation:

Staining Agent		Cleaning Procedure
•	Baby Oil	Step 1
•	Ketchup	Step 1
•	Chocolate	Step 1
•	Motor Oil	Step 1
•	Olive Oil	Step 1
•	Tea / Coffee	Step 1
•	Eye Shadow	Step 2
•	Crayon	Step 2
•	Grease	Step 2
•	Permanent Felt Tip Marker	Step 2
•	Mustard	Step 2
•	Lipstick	Step 2
•	Ball Point Pen	Step 2

Step 1: If cleaned immediately, us a clean dry cotton fabric. Wipe once, careful to remove most of the stain without spreading to surrounding area. Wipe more vigorously a second time if residue remains and proceed to Step 2.

Step 2: If residue remains use a straight application of the following contracted cleaners:

- Formula 409®
- Fantastik®

Wipe with a clean cloth, rinse with water and dry. If residue remains proceed to Step 3.

Step 3: More stubborn soiling may be eliminated using a cotton fabric soaked in 91% isopropyl (rubbing) alcohol. Wipe without spreading stain to surrounding area. A second application should be applied with vigorous rubbing in a circular motion. For highly textured material, a soft toothbrush is recommended to clean valleys and crevices. Wipe with a clean cloth, rinse with water and dry.



Cleaners only recommended if diluted per manufacturer's instructions. Topical cleaners must be wiped off with clean water and dried with a clean cloth following application. For any cleaner not listed, please inquire at 800,223,5466 x4882.