



1




Apply adhesive or double-sided tape to the back of the WM9/MF. If purchased with pre-installed double-sided tape or if you are installing the unit with screws, proceed to step 2.

2




Determine the position and location on the side of the work surface in which to apply the WM9/MF. Optional: If using screws for installation, position the WM9/MF on the work surface and use the screw guide to drill in the screws.

3




Apply pressure to the WM9/MF when placing against the work surface until it is held into position by the adhesive.

4



Place wires into position by dropping them into the opening on top of the WM9/MF.

TABLE OF CONTENTS:



..... WM9/MF