

# XALV WC LOW VOLTAGE INSTALLATION INSTRUCTIONS

- WARNING:** BEFORE PROCEEDING, READ ALL INSTRUCTIONS CAREFULLY TO INSURE PROPER AND SAFE INSTALLATION.
- WARNING:** RISK OF FIRE OR ELECTRICAL SHOCK. DISCONNECT POWER BEFORE INSTALLING OR SERVICING.
- WARNING:** RISK OF ELECTRICAL SHOCK. HIGH TEMPERATURES INSIDE LUMINAIRE. MAKE CERTAIN LINE VOLTAGE CORRESPONDS WITH STEPDOWN TRANSFORMERS VOLTAGE. (SEE TRANSFORMER MARKING LABEL)
- WARNING:** ALL WIRING TO BE PERFORMED PER NATIONAL ELECTRICAL CODE AND LOCAL CODE BY A QUALIFIED ELECTRICIAN.
- IMPORTANT:** WHEN SERVICING, ALWAYS WEAR EYE PROTECTION. MAKE SURE AREA BELOW FIXTURE IS CLEAR.
- NOTE:** IF LED MODULE IS DIRTY, OPERATING HOURS AND PERFORMANCE WILL SIGNIFICANTLY DECREASE.

## IMPORTANT SAFETY INSTRUCTIONS


### INSTRUCTIONS PERTAINING TO A RISK OF FIRE OR INJURY TO PERSONS

### CAUTION! LIGHTED FIXTURE & LAMP ARE HOT!

**WARNING:** TO REDUCE THE RISK OF FIRE OR INJURY TO PERSONS FOLLOW THESE IMPORTANT SAFETY INSTRUCTIONS.

1. FIXTURES GET HOT QUICKLY! TURN OFF/UNPLUG AND ALLOW TO COOL BEFORE REPLACING LED MODULE CONTACT ONLY SWITCH OR PLUG WHEN TURNING ON OR OFF.
2. DO NOT TOUCH HOT LENS, SHIELD, REAR BODY, OR ARM WHEN FIXTURE IS OPERATING OR RECENTLY TURNED OFF.
3. KEEP FIXTURE AWAY FROM COMBUSTIBLE MATERIALS. CONTACT WITH HOT FIXTURE MAY START A FIRE!
4. DO NOT INSTALL WITHIN 10 FEET OF A POOL, SPA, FOUNTAIN, OR OTHER BODY OF WATER.
5. DO NOT OPERATE WITH MISSING OR DAMAGED PARTS.
6. THIS IS A 12V FIXTURE. A REMOTE TRANSFORMER (POWER UNIT) IS REQUIRED.
7. FOR USE WITH MAXIMUM 25A, 15V POWER UNITS ONLY.
8. WALL MOUNTING CONNECTIONS ARE TO BE MADE IN SUCH A MANNER SO AS TO EXCLUDE WATER FROM J-BOX.
9. SAVE THESE INSTRUCTIONS

## XALV LED16 12V WCC WALL MOUNT




1. SLIDE SLEEVE & NYLON WASHER OVER LEADS & NIPPLE MOUNT AS SHOWN.
2. FEED FIXTURE LEADS & NIPPLE THRU CANOPY MOUNT HOLE & INSTALL LOCKNUT ON THE BACK SIDE OF CANOPY. ROTATE FIXTURE AS REQ'D & TIGHTEN LOCKNUT.
3. WCC SHOULD BE MOUNTED SO THAT SSUF SHIELD (FLUSH LENS SHIELD) IS AIMED UP, AND SCDR SHIELD (COLLAR SHIELD) IS AIMED DOWN.
4. APPLY CANOPY GASKET TO BACK SIDE OF CANOPY, WIRE WITH CONNECTORS SUPPLIED WITH FIXTURE, AND ATTACH CANOPY TO JUNCTION BOX (BY OTHERS). IF J-BOX IS RECESSED INTO WALL, CAULKING AROUND CANOPY TO PREVENT WATER ENTRY INTO STRUCTURE IS REQUIRED.



**INSTALLATION QUESTIONS?  
CALL LSI FIELD SERVICE  
800-436-7800 EXT 3300  
FAX 513-984-9723**


# XALV WC LOW VOLTAGE INSTALLATION INSTRUCTIONS

## XALV LED1612V WCU WALL MOUNT




1. SLIDE SLEEVE & NYLON WASHER OVER LEADS & NIPPLE MOUNT AS SHOWN.
2. FEED FIXTURE LEADS & NIPPLE THRU CANOPY MOUNT HOLE & INSTALL LOCKNUT ON THE BACK SIDE OF CANOPY. ROTATE FIXTURE AS REQ'D & TIGHTEN LOCKNUT.
3. WCU SHOULD BE MOUNTED SO SSUF SHIELD (FLUSH LENS SHIELD) IS AIMED UP.
4. APPLY CANOPY GASKET TO BACK SIDE OF CANOPY, WIRE WITH CONNECTORS SUPPLIED WITH FIXTURE, AND ATTACH CANOPY TO JUNCTION BOX (BY OTHERS).

## XALV LED16 12V WCD WALL MOUNT




1. SLIDE SLEEVE & NYLON WASHER OVER LEADS & NIPPLE MOUNT AS SHOWN.
2. FEED FIXTURE LEADS & NIPPLE THRU CANOPY MOUNT HOLE & INSTALL LOCKNUT ON THE BACK SIDE OF CANOPY. ROTATE FIXTURE AS REQ'D & TIGHTEN LOCKNUT.
3. WCD SHOULD BE MOUNTED SO THAT SCDR SHIELD (COLLAR SHIELD) IS AIMED DOWN.
4. APPLY CANOPY GASKET TO BACK SIDE OF CANOPY, WIRE WITH CONNECTORS SUPPLIED WITH FIXTURE, AND ATTACH CANOPY TO JUNCTION BOX (BY OTHERS).

## ADJUSTING LED16 MODULE BRIGHTNESS



LED16 HO PUSH BUTTON TO ADJUST BRIGHTNESS  
USE PEN TO TOGGLE BETWEEN 4 INTENSITY SETTINGS




LED16 SS SLIDE BUTTON TO ADJUST BRIGHTNESS  
USE PEN TO SWITCH BETWEEN HI/LO SETTINGS


# XALV WC LOW VOLTAGE INSTALLATION INSTRUCTIONS

## LED16 MODULE SERVICE


### WCU



### WCD



### WCC




### XALV WC LED MODULE REPLACEMENT SERVICE

1. TURN OFF POWER BEFORE SERVICING!
2. REMOVE SHIELD BY ROTATING COUNTER CLOCKWISE TO ACCESS LED MODULE.
3. REMOVE SCREWS RETAINING LED MODULE TO FIXTURE BODY.
4. REMOVE LED MODULE FROM SOCKET BY PULLING STRAIGHT UP UNTIL CONTACT PINS ARE CLEAR OF SOCKET. INSERT NEW MODULE OF SAME TYPE INTO SOCKET AND RE-INSTALL SCREWS
5. IF SHIELD / FIXTURE BODY O-RING IS DRY LUBRICATE WITH DOW CORNING 55 O-RING LUBRICANT. CONTACT LSI TO PURCHASE DOW CORNING 55 LUBRICANT IN 5.3-OZ TUBES.
6. REPLACE SHIELD BY SCREWING CLOCKWISE ONTO REAR BODY. TIGHTEN UNTIL SHIELD SEATS AGAINST REAR BODY.
7. CLEAN GLASS LENS WITH AMMONIA BASED CLEANER OR VINEGAR TO REMOVE MINERAL SCALE. CLEAN LENS AT LEAST ANNUALLY FOR OPTIMUM LIGHTING.

## ELECTRICAL CONNECTION OF FIXTURE TO POWER UNIT

**WARNING** TURN POWER UNIT OFF BEFORE CUTTING CABLE AND MAKING CONNECTIONS.

THE ALV SPLICE CONNECTORS PROVIDED WITH FIXTURE ARE WATERPROOF & ACCEPT NO.22 AWG THRU 10 AWG WIRE. (MIN. (4) NO. 20 AWG, MAX (3) NO. 12 AWG)



1. CUT MAIN CABLE AT SELECTED LOCATION
2. STRIP CABLE CONDUCTORS APPROX. 1/2".
3. CONNECT FIXTURE AS SHOWN MAKING SURE TO OBSERVE POLARITY OF MAIN CABLE FROM POWER UNIT. TWIST CONNECTORS FIRMLY.
4. ROUTE CABLE IN CLOSE PROXIMITY TO FIXTURE, MOUNT, OR BUILDING STRUCTURE TO PROTECT CONDUCTORS. SPLICE CONNECTIONS SHOULD BE 6" MAX. FROM FIXTURES.



INSTALLATION QUESTIONS?  
CALL LSI FIELD SERVICE  
800-436-7800 EXT 3300  
FAX 513-984-9723

# XALV WC LOW VOLTAGE INSTALLATION GUIDELINES

## BASIC FUNDAMENTALS OF LOW VOLTAGE LIGHTING

DESIGNING LOW VOLTAGE LIGHTING SYSTEMS TO MINIMIZE VOLTAGE DROP, AND MAXIMIZE UNIFORMITY OF LIGHTING EFFECT IS EVERY INSTALLERS GOAL. THERE ARE A FEW FACTORS, AND SEVERAL TECHNIQUES TO CONSIDER WHEN DESIGNING A LOW VOLTAGE LIGHTING SYSTEM. A MAXIMUM VOLTAGE DROP OF 10% OR MINIMUM VOLTAGE OF 10.8 VOLTS AT ANY POINT IN THE SYSTEM IS DESIRED. TO ACHIEVE NO MORE THAN A 10% VOLTAGE DROP USE THE FOLLOWING TECHNIQUES:

1. CABLE LAYOUT DESIGN USING MULTIPLE STRAIGHT RUNS IN SEVERAL DIRECTIONS. TEE CONNECTIONS REDUCE VOLTAGE DROP BY USING HEAVIER GAUGE CABLE FOR PRIMARY FEED. LOOPING THE MAIN CABLE GREATLY REDUCES VOLTAGE DROP, AND PROVIDES BETTER LIGHT UNIFORMITY. CARE MUST BE TAKEN TO MATCH CABLE POLARITY WHEN CONNECTING TO POWER UNIT.
2. CENTRALLY LOCATE YOUR POWER UNIT, OR IF BUDGET PERMITS USE SEVERAL SMALL POWER UNITS AT MULTIPLE LOCATIONS.
3. USE A MULTIPLE TAP SECONDARY POWER UNIT THAT PROVIDES 12V, 13V, 14V, OR 15V OUTPUT. MULTIPLE TAP POWER UNITS ARE VERY EFFECTIVE WHEN RUNNING LONGER DISTANCES, OR WHERE THE 1ST FIXTURE IS QUITE FAR FROM THE POWER UNIT. TO DETERMINE WHICH TAP TO USE MEASURE ACTUAL VOLTAGE WITH A DIGITAL VOLTMETER AT 1ST FIXTURE. FOR EXAMPLE START OUT USING THE 12V TAP, & MEASURED 1ST FIXTURE VOLTAGE IS 10V, SUBTRACT (12V-10V)=2V CORRECTION REQUIRED, (12V + 2V)=14V TAP IS REQUIRED FOR PROPER VOLTAGE.
4. USE PROPER GAUGE CABLE FOR THE LOAD & RUN LENGTH. VERIFY WITH AMP PROBE YOU HAVE NO MORE THAN 16 AMPS ON EACH 12/2 CABLE, AND NO MORE THAN 25 AMPS FOR ANY LARGER CABLE (10GA OR 8GA).
5. AT THE POWER UNIT USE YOUR AMP PROBE TO VERIFY YOU HAVE NOT EXCEEDED THE MAXIMUM ALLOWABLE AMPERAGE FOR THE TRANSFORMER. SEE POWER UNIT RATINGS LABEL FOR MAXIMUM CURRENT ALLOWABLE.

6. TO CALCULATE VOLTAGE DROP ON A CABLE RUN USE THE FOLLOWING FORMULA:

AMPS =  $\frac{\text{WATTS}}{\text{VOLTS}}$     EXAMPLE:  $\text{AMPS} = \frac{100\text{W}}{12\text{V}} = 8.33\text{A}$      $(8.33\text{A} \times 100\text{FT} \times 2 \times .00162) = 2.698\text{V DROP}$   
IN A 100FT RUN OF 12GA CABLE

VOLTAGE DROP RESISTANCE PER FOOT OF CABLE (CONSTANTS)				
WIRE SIZE	18GA	0.006385	10GA	0.001080
	16GA	0.004016	8GA	0.000640
	14GA	0.002525	6GA	0.000395
	12GA	0.001620	4GA	0.000249

