

LINEA CONFERENCE TABLE

HBF

D1013-0001-00


PAGE 1

ASSEMBLY INSTRUCTIONS

GENERAL NOTES


1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.
3. TWO PERSON ASSEMBLY REQUIRED

HARDWARE B




1 INSTALL GLIDES

-THREAD IN ALL ADJUSTABLE GLIDES (A) INTO BASE GLIDE HOLES



2 ATTACH WIRE MANAGEMENT CLIPS

-SLIDE EQUAL NUMBER OF WIRE MANAGERS (B) INTO THE INSIDE OF EACH SUPPORT RAIL



LINEA CONFERENCE TABLE



HBF

D1013-0001-00

PAGE 2

3 ALIGN AND ATTACH SUPPORT RAILS



- ALIGN TWO RAILS WITH MOUNTING HOLES IN SIDES OF BASE
- SECURE TIGHTLY FROM INSIDE BASE WITH CONNECTOR BOLTS (C)
- MAKE SURE TO PROPERLY ALIGN THE ALUMINUM EXTRUSIONS TO FULLY CLOSE GAPS
- REPEAT THIS PROCESS TO SECURE REMAINING RAIL ENDS TO BASES



4 INSTALL SPLINES

- INSERT SPLINES (D) IN ONE GROOVE OF EACH JOINT
- PLACE TOPS ON THE BASES IN FINAL LOCATION
- SLIDE TOPS TOGETHER ALIGNING THE SPLINES TO THE GROOVE



NOTE:
DO NOT LIFT TOP ONCE JOINT FASTENERS ARE
INSTALLED. UNEVEN LIFTING WILL PINCH THE
TOP VENEER AT THE SEAM CAUSING A BUBBLE
IN THE VENEER.



5 ALIGN AND SECURE WORKSURFACE

- INSTALL ONE JOINT CONNECTOR (E) ON EACH END OF
JOINT TO ENSURE PROPER ALIGNMENT
- INSTALL REMAINING JOINT CONNECTORS

NOTE: ALWAYS INSTALL THE TOP RIGHT
SIDE UP ON TOP OF THE BASES. USE
SAWHORSES IF NECESSARY TO SUPPORT
THE TOP BEFORE THE BASES ARE ATTACHED.



NOTE: TOP WILL HAVE TO BE MOVED FROM SIDE TO SIDE
SLIGHTLY IN ORDER TO INSTALL ALL JOINT CONNECTORS

LINEA CONFERENCE TABLE


HBF

D1013-0001-00


PAGE 3

6 SECURE WORKSURFACE TO BASES

- CENTER TOP ON BASES
- ALIGN LOCATION HOLES ON BOTTOM OF WORKSURFACE TO OUTER SCREW HOLE IN THE BASE FLAT PLATES
- INSTALL ONE 3/4" SCREW (F) IN EACH CORNER TO ENSURE PROPER ALIGNMENT
- ONCE ALIGNED, FINISH SECURING FLAT PLATES TO WORKSURFACE




DETAIL E




SCALE 0.037

7 SECURE RAILS TO WORKSURFACE

- SECURE RAILS TO WORKSURFACE USING THE MOUNTING HOLES IN THE RAILS
- WITH 3/4" SCREWS (G)
- DO THIS FOR ALL RAILS




SEE DETAIL F




DETAIL F

8 INSTALL BOTTOM PANEL (FOR WIRE MANAGEMENT)



SEE DETAIL G

- SECURE BOTTOM PANEL TO UNDERSIDE OF THE SIDE RAILS USING THUMB SCREW (H)



DETAIL G

8 ADJUST GLIDES TO LEVEL TABLE