

NUCRAFT

Merino Casegood Installation Instructions

Before Beginning Installation

- Read through the entire instruction thoroughly
- A minimum of 2 people are required for this assembly
- These instructions reflect typical assemblies; They may not match your specific configuration

Required Tools & Hardware

- Drill Driver
- #2- #3 Phillips Bit
- #2 Square Bit
- 3/8" Nut Driver
- Laser Level
- 5/16" Wrench

1



2



3




4



5




Merino Free Standing




Merino Free Standing Exploded

1. Freestanding Desk
2. Work Surface
3. Lateral File Pedestal
4. Box, Box, File Pedestal
5. Tack Board
6. Overhead
7. Tower




Merino U-Shape




Merino U-Shape Exploded

1. Desk
2. Work Surface
3. Lateral File Pedestal
4. Box, Box, File Pedestal
5. Tack Board
6. Overhead
7. Tower
8. Access Panel
9. Corner Support
10. Bridge




Merino L-Shape




Merino L-Shape Exploded

1. Desk
2. Work Surface
3. Lateral File Pedestal
4. Box, Box, File Pedestal
5. Tack Board
6. Overhead
7. Overhead Hood
8. Corner Support
9. Power Option




Merino T-Shape



Merino T-Shape Exploded


1. Desk
2. Work Surface
3. Lateral File Pedestal
4. Box, Box, File Pedestal
5. Tack Board
6. Overhead
7. Overhead Hood
8. Access Panel
9. Tower



Step 1

Installing the Credenza


- Locate the Pedestals and set in place. Level.
- Align work surface with mitered edge on pedestal(s). Attach using **3** & **5**
- If station has additional work surfaces, attach those the same way and connect using mending plates and screws **4**



Step 2

Attaching Corner Support

- Install connector pins **1** to the work surface.
- Lower the work surface onto the corner support, aligning the pins with the corresponding holes in the corner support.
- Secure by turning the cams $\frac{1}{2}$ turn clockwise.




Step 3

Installing Stanchions

(If wall hung, skip to step 5)

- Loosen the stanchion channel bolts. Do not remove.
- Slide the stanchions in the channels. Adjust glides on the stanchions until scribe line is flush with work surface.
- Tighten the stanchion channel bolts.
- Attach cross members using 3/8" bolts.



Step 4

Installing Tack Board & Overhead

- Attach the tack board using the pre installed “Z” clips on the back side. Press down to fully engage.
- Hang the overhead on the top of the stanchions.
- Adjust side to side to align with work surface.



Step 5

Attaching the Access Panel


- Align the access panel so the raffle connectors are in line with the studs.
- Place on studs and tighten with a phillips screwdriver by turning clockwise.



Step 6

Installing Wall Mounted Tack Board & Overhead

- Ensure work surface is level.
- Reference numbers in the table below. Measurements are to the bottom of cleat.
- Attach wall cleats. (lag screws for a backed wall, toggles for non backed wall.
- Install the tack board.
- Install the overhead.




	Open Shelf		Case Overhead		A
	Single High	Double High	Single High	Double High	
Tackboard 21.25"	x	x	31.923"	44.173"	A
23.5"	32.049"	x	34.173"	x	
33.5"	42.049"	x	44.173"	x	
21.844"	x	42.05"	x	x	

Tackboard	WS 2		B
	Cleat		
21.25"	15.648"		
23.5"	17.898"		
33.5"	27.898"		
21.844"	16.242"		

Step 7

Attaching the Sliding Hood

- Remove the wing nuts from the track on the back of the overhead.
- Lifting hood over the back of the overhead, carefully align the holes on the hood with the studs in the tracks.
- Attach wing nuts to secure hood on the overhead.



Step 8

Installing Glass Desk

- Locate the glass top. (shipped loose)
- With the desk in place and properly leveled (leveling is important to ensure a proper miter alignment) place glass top in place.
- Use glass pods for this installation.

