

Assembly Instructions ■

Ruckus® Tote Storage

Optional Laminate Worksurface

July 2019




Figure 1




Figure 2



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.

Tools Required

- Tape Measure
- Cordless Power Drill
- Double-Sided Tape
- $\frac{7}{64}$ " drill bit
- #3 Phillips Tip

Optional Laminate Worksurface Assembly

1. Clean the top of tote storage unit with warm water and mild detergent, then rinse and wipe dry.
2. If casters are assembled to the tote storage unit, engage the locks on the casters to prevent the unit from moving (Figure 1 & Detail A).
3. Use a tape measure and pencil to locate and mark four pilot hole locations to the top of the storage unit. As illustrated, each marked location should be near each corner and be $2\frac{1}{2}$ " in from the front/back and right/left-hand sides of the top of the storage unit (Figure 1).
4. To gain access for drilling and to install fasteners, remove the top totes from the storage unit where applicable (Figure 2).

Ruckus® Tote Storage - Optional Laminate Worksurface

Assembly Instructions



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.

5. From the top of the unit, drill a $\frac{1}{4}$ " diameter hole at each marked location. When all appropriate mounting holes have been drilled, remove debris from storage unit (Figure 3).

6. Apply 3" long strips of double-sided tape to top corners of the storage unit, about $\frac{1}{4}$ " from the edges of the front and back at each side (Figure 4 & Detail B).

Note: Two or more people are required to correctly align and position the laminate top onto the storage unit. Ensure the top is positioned correctly before setting the top onto the tape as it will be difficult to move afterward.

7. Remove the backing from the double-sided tape adhered to the storage unit top. Carefully center the laminate top over the storage unit such that the top is flush with the front, back and sides of the unit (Figure 5).

Note: For the step below, it is advised to either have a second person press down on the laminate top while driving in each screw, or pre-drill each hole using a $\frac{1}{8}$ " drill bit to no deeper than $\frac{1}{2}$ " before driving in screws.

8. Assure that the laminate top is properly aligned on the storage unit. From inside the storage unit at the pilot holes, use a power drill with #3 Phillips tip and #14 x $\frac{7}{8}$ " Phillips Pan Head screw to secure the storage unit top to the laminate top at each corner (Figure 6).

9. Replace the totes if removed in step 4.




Figure 3




Figure 4




Figure 5




Figure 6