

Mobile Workstation - Fixed Surface

Tools Required

- 3mm hex bit
- #2 Phillips bit
- Drill or impact driver
- Tape Measure

Hardware

- 12 - M5 X 8 CAP SCREWS
- 8 - #10 x 5/8" Phillips Woodscrew.
- 2 - black wood dowels
- 2 - springs
- 4 - #8 X 3/4" wood screws

Installation

1. Unpack all components.
 2. Assemble metal frame by placing Left Frame on clean soft surface. Slide the Connector Rail over the upper "U" bracket and secure with 2 M5 Flathead screws. See Figure A
 3. Slide Lower Horizontal Weldment over lower Brackets but do not install the screws at this time. See Figure A
 4. Place the Right Frame assembly on top of assembly and secure in place with remaining 2 M5 Flathead screws into the connector rail. Screws holding the Lower Horizontal Weldment will be installed after back panel has been installed. See Figure A
 5. Install back panel by first flipping the cart assembly on its front as seen in Figure B. Place a supplied spring and wood dowel in each side of the back panel. Slide the dowels on the top of the back panels into the oblong holes on the Connector Rail. Compress the springs on the sides by pressing the dowels into the holes while pivoting the back panel into place until the bottom of the back panel is seated securely on the Lower Horizontal Weldment. Without the screws in place, the Lower Horizontal Weldment should slide down and provide room to insert the back panel.
 6. The spring should push the side dowels into the mating oblong holes on the frame and you should here a "Click". Secure the bottom of the back panel to the Lower Horizontal Rail with the supplied #8 -1" wood screws. Secure the Lower Horizontal Weldment with the remaining 4 M5 Flathead screws.
- Tip:** Ensure any loose felt is completely tucked into seem by pushing it into seem using a plastic card.

Figure A





Figure B



Installation (Continued)

4. Install the 2 crossrails and worksurface support frame by first sliding the 8 Surface Brackets into the mating slots on the welded frames. Tap into place using rubber mallet. See Figure C.

5. Install the worksurface by first setting the cart assembly upright. Place the surface, surface side up, on the worksurface support frame, holding a 1" inset from the front of the frame. Secure in place with the 8 - #8 X 5/8" woodscrews.

Figure C




Figure D

