



1. UNPACK & ORGANIZE HARDWARE, TOPS AND BASES
2. FLIP TOP UPSIDE DOWN (ON A SOFT NON-SCRATCHING SURFACE) HAVE THE FRONT EDGE FACING YOU ON AND THE PILOT HOLES VISIBLE
3. FLIP ASSEMBLED BASE ONTO THE TOP
4. ALIGN THE TOP SUPPORT PLATE (A) SO THE NOTCHED CORNERS (B) ARE FACING THE FRONT EDGE
5. ATTACH THE PLATE TO TOP USING #8 x 5/8" WOOD SCREWS (C) PROVIDED
6. FASTEN SMALL PLASTIC CABLE CLIP (D) TO BACK CENTERED SCREW OF SUPPORT PLATE (FOR ADJ. BASE ONLY)
7. POSITION HANDLE (F) BY WRAPPING CABLE (G) AROUND THE COLUMN (SEE DIAGRAM) AND PLACING 4 PREPARED HOLES
8. ATTACH HANDLE USING #8 x 5/8" WOOD SCREWS (C) PROVIDED
9. ALIGN THE "U" BRACKET (E) BY PUSHING IT UP AGAINST THE BACK EDGE OF THE SUPPORT PLATE (PILOT HOLES WILL BE VISIBLE THROUGH HOLES IN BRACKET)
10. ATTACH THE "U" BRACKET TO THE TOP USING THE #8 x 5/8" WOOD SCREWS (C) PROVIDED
11. FASTEN SMALL PLASTIC CABLE CLIP (D) TO BACK RIGHT CORNER OF SUPPORT PLATE
12. INSERT GROMMET (GROMMET AND FRAME) (I) - NO FASTENERS REQUIRED
13. ATTACH 2" WIRE MANAGEMENT WHERE NEEDED (ABOVE DRAWING SHOWS CORE TOWER LOCATED ON FRONT)

13. PLACE THE SHROUD WITH PINS (J) INTO THE 4 HOLES ON THE TOP (IT'S BEST TO START ON THE BACK 2 AND THEN BEND EACH SIDE OF THE PANEL IN TOWARD THE CENTER OF THE TOP UNTIL IT DROPS INTO THE HOLES)

14. AT EACH LOCATION ATTACH USING A CUP WASHER AND A #4 BOLT, TIGHTEN (K)

VOX MONOGRAM

JOINING MULTI MONOGRAM TABLES TOGETHER



INSTALLATION

1. LIFT SPINNING (A) ON BASE TO ACCESS THE HOLES (B) FOR ATTACHING JOINER PLATE
2. SLIDE THE JOINER PLATE (C) UNDER THE DISC FOOT (D)
3. ALIGN THE CORRECT HOLES WITH THE HOLES ON THE DISC FOOT. **SEE PLAN VIEWS** ON RIGHT FOR CONFIGURATION TYPES
4. USING THE 1/4-20 CHICAGO BOLT (E), SCREW BOLT THROUGH THE PLATE AND INTO THE JOINER PLATE
5. SLIDE THE NEXT VOX MONOGRAM TABLE OVER THE JOINING PLATE AND REPEAT STEPS 3 & 4
6. CONTINUE REPEATING TILL DESIRED CONFIGURATION IS ACHIEVED