

ELKAY® BIM Content Library

User Guide – Bottle Filling Stations -

Products ➔ Drinking Water ➔ Bottle Filling Stations ➔ On Wall



LZSTLDDWSLK



EZSTL8WSLK



EZSTLDDWSLK



EZSTLG8WSLK



EZSTLG8WSSK



LZSTL8WSVRLK



LZSTL8WSVRSLK



LZSTLDDWSVRLK



LZSTLDDWSVRLK



EZOOTL8WSSK



EZOTL8WSLK



EZOTL8WSSK



EZSTL8WSSK



Figure 1: EZ Family

LOADING THE MODELS

How to Load the Elkay Family

It is recommended the steps outlined below are followed to properly load the BIM component into a project.

1. Open a Revit Project File (.RVT) and navigate to the Plan View.
2. Go to the 'Insert' tab on the Revit ribbon and select 'Load Family'




Figure 2: Loading the Family into a Project

3. Navigate to the location of the downloaded Elkay Bottle Filling Stations (RFA file)
4. Click 'OK' to load the component into the project

The family is now copied and embedded into the project. It can be selected from the components button located on the 'Architecture' tab on the main Revit Ribbon.

How to Access the Data for the EZ Family

BIM File Name: **BIM Model –Elkay_Drinking-Water_Bottle-Filling-Stations_EZ_Onwall_St2.rfa**



Master BIM Model : BIM Model –Elkay_ Drinking-Water_ Bottle-Filling-Stations_EZ_Onwall_St2.rfa

SKU's List in BIM

Type Properties

Family: **Elkay_Drinking-Water_Bottle-Filling-Stations_EZ_Onwall_St2** Load...

Type: **EZSTL8WSLK** Duplicate... Rename...

Type Parameters

Constructive	EZSTL8WSLK
Special Features	EZSTL8WSLK
Finish	EZSTL8WSLK
Power	EZSTL8WSLK
Bubbler Style	EZSTL8WSLK
Activation	EZSTL8WSLK
Chilling Cap	EZSTL8WSLK
Full Load	EZSTL8WSLK
Rated Watts	EZSTL8WSLK
Dimensions	EZSTL8WSLK
Approx. Shipping Weight	101 lbs
Installation Location	Indoor
Number of Stations	2

Materials and Finishes

Finish_1	Light Gray Granite
----------	--------------------

Mechanical

WPU	
HWPU	
CWP	


Identity Data

Type Image	
Keynote	
Model	EZSTL8WSLK
Manufacturer	Elkay
Type Comments	
URL	
Description	

What do these properties do?

<< Previous OK Cancel Apply

SKU's Configured BIM Model



LZSTL8WSLK





LZSTL8WSSK



LOADING THE IFC MODEL

How to Load the Elkay IFC Model in Revit

To use an ELKAY IFC model, link the IFC file to a Revit model.

1. (Optional) Before linking an IFC file, click File tab ➤ Open ➤  (IFC Options) and use the Import IFC Options dialog to do the following:
 - Select a default Revit template to use for IFC files.
Note: If a default template is not selected, the first template listed under File Locations in Revit Options will be used.
2. Open the Revit model.
3. Click Insert tab ➤ Link panel ➤  (Link IFC).
4. In the Open IFC File dialog, navigate to the IFC file, select it, and click Open.