




PART #

PGRP15


310.318.2491 • 800.523.1269 • www.mockett.com




**TOP VIEW
BASE MOUNT**



**FRONT VIEW
VERTICAL GRIP**




**FRONT VIEW
BASE MOUNT**




**SIDE VIEW
VERTICAL GRIP**

NOTE:

- Weight capacity is 30 lbs. MAX. per set.
- Panel thickness is 1/8" MAX.
- Panel width is 48" MAX.
- Maximum spacing between panel grips is 40" on center.
- Recommend installing into ceiling joist.



Determine the position and location of the panel grips and drill (2) holes into the panel.



Drill pilot holes for the base mount. (NOTE: Spacing between the center of the base mounts should measure the same as the O.C. of the pre-drilled holes on the panel in Step 1.)

TABLE OF CONTENTS:



..... 2X Base Mount



..... 6X 1-1/2" No. 8 Wood Screws




..... 2X Vertical Grip




..... 1X 10' Long 3/64" DIA. Metal Wire




..... 6X HK-ANCHOR2



Align the base mount with the pilot holes and secure by using (3) wood screws. (Note: Make sure top mount is secured on the base plate before installing on the work surface. Use a 5/32" hex key to secure parts if necessary. Hex key NOT INCLUDED.) Repeat step for the other base mount.



Cut (2) pieces of metal wire to desired length using a pair of wire cutters. Attach metal wire to vertical grip and top mount by sliding the wire into the wire slots and secure by using a 3/32" hex key to tighten the set screws. (NOTE: Wire cutters and hex key NOT INCLUDED.)



Align vertical grip with the hole on the panel and secure by tightening the set screw. Repeat step for other vertical grip.