


Cona

KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3
tel 416 759 5665 fax 416 759 5723 1 800 724 5665
www.keilhauer.com info@keilhauer.com

1. Seat Height Adjustment (while seated)


Use this
(to raise or
lower seat)



Use the paddle shaped lever on the right side underneath the seat
To raise lift your weight off the seat while lifting the front of the lever
To lower sit on the seat while lifting the front of the lever

2. Tilt Tension

3. Tilt Lock (while seated)



Use the adjustment knob at the end of the height adjustment lever

To increase tension slide the knob out and turn the knob clockwise. Slide knob back into place.

To decrease tension slide the knob out and turn the knob counter-clockwise. Slide knob back into place.

Use the paddle shaped lever on the left side underneath the seat

To unlock tilt pull the front of the lever up and tilt back slightly

To lock tilt recline to your desired position and push the front of the lever down

